



LISTEN • DEVELOP • LEAD

**Operation, Installation & Maintenance Manual for
Diesel Engine Fire Pump Controller
Automatic Controller
Model GPD**












	Table of Contents
	1. Information
	2. Installation
	3. Main Features
	4. Home
	5. Alarms
	6. Configuration
	7. History
	8. Technical Documentation



Table of Contents

Table of Contents.....	3
Introduction.....	6
Types of Diesel Engine Fire Pump Controllers	6
Methods of starting/stopping	6
METHODS OF STARTING.....	
METHODS OF STOPPING	
Installation	8
Location	8
Mounting	8
Wiring and Connections	9
Water Connections	9
Electrical Wiring	9
Electrical Connections.....	9
Sizing.....	9
Incoming Power Connections.....	9
Circuit protection	9
Terminal Strips Descriptions	10
Quick Start-Up Guide.....	11
Main Features	20
The ViZiTouch.....	20
Alarm bell.....	21
First Setup	21
Home.....	22
Home (Membrane button)	22
Home	22
Gauges Page.....	25
Home > Gauges.....	25
Screen Saver	25
Alarms	26
Alarms (Membrane button).....	26
Alarms.....	26
Configuration	30
Config (Membrane button)	30
Config	30
NumPad Page.....	31
Date and Time Page	32
User Login Page / KeyPad Page.....	33

Advanced Configuration Page.....	34
Config > Advanced.....	34
Details of the Advanced Configuration Page	35
Volt-Current Calibration.....	35
Config > Advanced > Volt Calibration –	Current Calibration
Timers Page	36
Config > Advanced > Timers 1-2.....	36
Inputs/Outputs Configuration.....	37
Config > Advanced > Inputs Selection-Configuration-Outputs Configuration	37
Inputs/Outputs Expansion board 1-2-3-4.....	39
Config > Advanced > IO Expansion 1-2-3-4	39
Update Program Page	40
Factory Settings	40
Config > Advanced > Factory Settings 1-2-3-4-5.....	40
Reset to Factory Settings Page.....	44
Service Page.....	45
Config > Advanced > Service	45
New Pump Curve	46
Service > New Pump Curve	46
Automatic Pump Curve Mode Disabled	47
The Sensors Pages.....	48
Details of the Debug Page	52
Calibration.....	52
Config > Advanced > Debug > Calibration	52
IO Debug	52
Config > Advanced > Debug > IO	52
Config > Advanced > Debug > Expansion 1-2-3-4	53
Config > Advanced > Debug > Expansion 1-2-3-4	53
History	54
History (Membrane button).....	54
History.....	54
Details of the History Page.....	55
Events Page	55
History > Events Log.....	55
Download to USB Device	55
History > Download to USB.....	55
The Statistics	57
First/Last Service Statistics	57

History > Statistics since first/last service	57
All Time Statistics	58
History > All Time Statistics	58
Pressure Curves	58
Graphical Mode	58
History > Pressure Log Curves	58
Textual Mode	59
History > Pressure Log Text	59
Power Curves	60
Graphical Mode	60
History > Power Log Curves	60
Textual Mode	61
History > Power Log Text	61
Pump Curves	62
History > Pump Curves	62
Technical Documents	63
Pre-field Acceptance Test	64
Field Acceptance Test Report	66

Introduction



Diesel engine fire pump controllers are designed to automatically start a diesel engine driven fire pump upon detection of a pressure drop in the fire protection system. A diesel engine fire pump controller provides automatic & manual starting and stopping. An automatic start is controlled by a pressure transducer or by remote automatic devices as deluge valve. A manual start is controlled by remote manual button or by controller pushbutton. The automatic shutdown option provides a 30-minutes automatic stop after automatic start once all starting causes have returned to normal. The diesel engine fire pump controller includes two battery chargers to maintain the engine batteries continuously charged.

Types of Diesel Engine Fire Pump Controllers

FIRE PUMP CATALOGUE NUMBER

MODEL NO. EXAMPLE : GPD-12-120		
Model Prefix	GPD	
Battery Voltage	12 : 12V	24 : 24V
Incoming Voltage	120: 110/120V 50/60Hz	220: 208/240V 50/60Hz

Methods of starting/stopping

The controllers are available as combination automatic / non-automatic with provision for manual or automatic shutdown (automatic shutdown only possible after automatic start)

METHODS OF STARTING

AUTOMATIC START

The controller will start automatically on low pressure detection by the pressure sensor when pressure drops below the cut-in threshold. The controller must be in automatic mode.

MANUAL START

The engine can be started by pressing the CRANK 1 or and/or CRANK 2 push button, regardless of the system pressure, when the Main Selector switch is in the HAND position. The Fuel Solenoid Valve will open as soon as a CRANK button is pressed and will remain in this state.

REMOTE MANUAL START

The engine can be started from a remote location by momentarily closing a contact of a manual push button.

REMOTE AUTOMATIC START, DELUGE VALVE START

The engine can be started from a remote location by momentarily opening a contact connected to an automatic device. The controller must be in automatic mode.

SEQUENTIAL START

In case of multiple pump application, it may be necessary to delay the starting of each motor in case of water pressure drop to prevent simultaneous starting of all motors.

FLOW START, HIGH ZONE START

The controller can be started by opening/closing a contact on the FLOW/ZONE START/STOP input.

WEEKLY START

The engine can be started (and stopped) automatically at the preprogrammed time.

TEST START

The motor can be started automatically for a preprogrammed time by pressing the run test button.

METHODS OF STOPPING

MANUAL STOP

Manual stop is done by pressing the STOP push button. Note that pressing the stop push button will stop the engine only if all starting causes have disappeared.

AUTOMATIC STOP

The automatic stop is possible only after an automatic start and this function must be activated. When this function is enabled, the motor is automatically stopped 30 minutes after the restoration of the pressure (above the cut-out threshold) given that no other run cause is present.

FLOW STOP, HIGH ZONE STOP

If the controller has been started by the FLOW/ZONE START/STOP input and that the signal has returned to normal, the motor will be stopped given that no other run cause is present.

EMERGENCY STOP

The emergency stop is always possible in any running condition and is done by positioning the main selector switch to the OFF position.

Installation



This diesel controller is UL listed and FM certified. The controller is built in accordance with the latest edition of the National Fire Protection Association standard for the Installation of Centrifugal Fire Pumps, NFPA No.20 (Centrifugal Fire Pumps 2013 Edition). The controller is intended to be installed in accordance to NFPA 20-2013 and

in the USA	National Electrical Code NFPA 70
In Canada	Canadian Electrical Code, Part 1
Others *	Local Electrical Codes *

* Only American and Canadian applicable codes have been considered during the design of the controllers and the selection of components.

Location

The controller shall be located as close as practical to the engine/motor it controls and shall be within sight of the engine/motor. The controller shall be located or protected that it will not be damaged by water escaping from pump or pump connections. Current carrying parts of controller shall be not less than 12 in. (305 mm) above the floor level.

Working clearances around controller shall comply with NFPA 70, National Electrical Code, Article 110 or C22.1, Canadian Electrical Code, Article 26.302 or other local codes.

The controller is suitable for use in locations subject to a moderate degree of moisture, such as a damp basement. The pump room ambient temperature shall be between 41°F (5°C) and 104°F (40°C).

The standard controller enclosure is rated NEMA 2. It is the installer's responsibility to insure that either the standard enclosure meets the ambient conditions or that an enclosure with an appropriate rating has been provided. Controllers must be installed inside a building and they are not designed for outside environment. The paint color may change if controller is exposed to ultraviolet rays for a long period of time.

Mounting

The fire pump controller shall be mounted in a substantial manner on a single incombustible supporting structure. Wall mounted controller shall be attached to the structure or wall using all four (4) mounting ears provided on the controller with hardware designed to support the weight of the controller at a height not less than 12 in. (305 mm) above floor level. Floor mounted controller shall be attached to the floor using all holes provided on the mounting feet with hardware designed to support the weight of the controller. The mounting feet provide the necessary 12 in. (305 mm) clearance for current carrying parts.

A concrete slab is recommended to avoid water accumulation at the controller's feet.

Wiring and Connections

Water Connections

The controller must be connected to the pipe system according to NFPA20-2013 and also to a drain pipe. The water connections are on the left side of the controller. The connection to the system pressure is a Male ½ NPT. The connection to the drain is a tapered connection for plastic tubing.

Electrical Wiring

The electrical wiring between the power source and the diesel engine fire pump controller shall meet the NFPA 20–2013, Chapter 12.3.5.1 and 12.3.5.2, NFPA 70 National Electrical Code Article 695 or C22.1 Canadian Electrical Code, Section 32-200 or other local codes.

Electrical Connections

A licensed electrician must supervise the electrical connections. The dimension drawings show the area suitable for incoming power and motor connections. No other location shall be used. Only watertight hub fittings shall be used when entering the cabinet to preserve the NEMA rating of the cabinet. The installer is responsible for adequate protection of the fire pump controller components against metallic debris or drilling chips. Failure to do so may cause injuries to personnel, damage the controller and subsequently void warranty.

Sizing

Wiring between controller and engine (terminals 301,302,303,304,305,310,311,312,2,3,4,5) must be stranded #14AWG as minimum.

Wiring between controller and engine (terminals 1,9,10,12) must be stranded #10AWG as minimum.

Wiring between controller and engine (terminals 6,8,11) must be stranded #8AWG as minimum.

Power supply wiring must be stranded #14 AWG as minimum.

Incoming power supply terminals are sized for #16 to #6 AWG wire.


Incoming Power Connections

Diesel engine driven fire pump controller shall be powered by a dedicated source protected by a fuse or circuit breaker. Verify the label on the cabinet to select the correct protection. Always follow this procedure when connecting or disconnecting the controller: Connect both batteries before connecting the AC power. Disconnect the AC power before disconnecting the batteries. Disconnecting the batteries while the AC is connected may result in severe damage to the controller electronic boards.

Circuit protection

CB1 protects battery charger 1 and CB2 protects battery charger 2. CB3 protects control circuit from battery 1 and CB4 protects control circuit from battery 2. Again, please always follow this procedure when connecting or disconnecting the controller: Connect both batteries before connecting the AC power. Disconnect the AC power before disconnecting the batteries.

Terminal Strips Descriptions



A-F : Alarm Output Terminals

(DPDT Relay, 11/21:Common, 12/22:Normally Closed, 14/24:Normally Opened):

- A Controller Trouble (Fail safe)
- B Engine Run
- C Main SS in HAND/OFF position
- D Engine Trouble
- E Pump Room Alarm
- F Optional Output 1

G-K : Field Inputs Terminal

(Dry Contact Only: Voltage Free):

- G Low Fuel Level (NO)
- H Remote Automatic Start (NC)
- I Deluge Valve Start (NC)
- J Fuel Tank Leak (NO)
- K High Fuel Level (NO)
- L Engine RPM Magnetic Pickup
- M ECMS Elec. Ctrl. Switch
- N FIM Fuel Injection Malfunction
- O ECMW Elec. Ctrl. Warning
- P ECMF Elec. Ctrl. Fault
- Q PLD Low Suction Pressure
- R High Raw Water Temperature
- S Low Raw Water Flow
- T LET Low Engine Temperature

U : Engine Terminals :

The terminals are numbered according to the standard:

- 1 FS : fuel solenoid valve
(energized to start)
- 2 ER : engine run contact
- 3 OS : engine overspeed contact
- 4 OP : engine oil pressure contact
- 5 WT : engine coolant thermostat
contact
- 6 B1 : battery #1 positive
- 8 B2 : battery #2 positive
- 9 C1 : start contactor #1
- 10 C2 : start contactor #2
- 11 GND : Ground
- 12 ST : stop fuel solenoid valve
(ETS - energized to stop)


V : Analog inputs / Solenoid Valve:

SOL V. Test Solenoid Valve

- AI1 Discharge Pressure transducer
- AI2 Optional additional Discharge Pressure transducer
- AI3 Water Level or Suction Pressure transducer
- AI4 Fuel Level analog input
- AI5 Flow or Spare Temperature analog input
- W Optional Input for analog AC reading
- X CANBUS to IO cards
- Y CANBUS to ViZiTouch
- Z Factory reserved power connections


Quick Start-Up Guide

1




1-The rating label is the most important label. It must be read carefully to ensure the compatibility between the controller and the installation.


2




2-Verify that the controller is installed securely on the wall, or optionally on the mounting stand. Verify the Main Selector Switch is in the "OFF" position.




3-Open the controller's door and verify all circuit breakers are in the lower "OFF" position.




4-Verify and/or install the proper water connections for the water input and the drain. They must be securely installed and tightened. Refer to the silkscreen markings on the plastic cover.




5-Connect all cables between the engine control panel and the controller engine terminal (Identified as "S" on the IO board diagram displayed in the Terminal Strips Descriptions in the manual). Secure with the appropriate torque as indicated on the torque label and verify all connections. Connect the AC main line and ground to the AC terminal in the controller.




6-Activate all breakers by setting them to the ON position. The controller will boot up for the first time.




7- The “First Setup” page replaces the Homepage until the “First Setup” is done. Verify that the controller reads the batteries voltage and current. Verify the “AC” is “OK” and not “FAIL”. Verify that the pressure reading is correct.




8-Turn the Main Selector Switch in the “HAND” position.




9-Before trying to start the engine, verify that the engine setup is complete and the exhaust pipe is connected properly. Start the engine manually by using the “Crank 1” membrane button. Verify that the engine has started and is running properly.



10-Stop the engine by turning the “Main Selector Switch” in the “OFF” position.




11-Click on the “Go to Setup” button. The “Config” page is now visible. Click on the “padlock” button to log in with your password. If needed, read the “User Login / KeyPad” section for more information on how to enter your password. Once a valid password is confirmed, the “Config” page will be visible again with the “padlock” showing that it is open the actual user security level.




12- Select the controller pressure units, cut-in and cut-out. Verify that all other parameters on the setup page are correct.

13-Once the configuration is done, click on the “Home” membrane button. The “First Setup” page will be displayed.




13-14- When satisfied with the controller settings, press the “Home” button on the membrane, acknowledge the changes by pressing the done button. If the done button is unavailable, ensure that a sufficient authorization code has been entered.




15- Proceed with the download step to save the report.

16



16- Press the home page button to verify that the displayed values are correct.

17



17-Turn the "Main Selector Switch" to the "AUTO" position. This is the preferred position and from now on, the "Main Selector Switch" should always remain in that position.




18- The first Setup is now completed. The controller is fully installed and configured.

Main Features



The ViZiTouch



A: Power LED: Indicates if the ViZiTouch is properly powered.

B: Touch Screen: 4.2 inches color touch screen LCD.

C: Alarm LED: Indicates if an alarm is currently active.

D: Front USB Connector: USB Device connector used for file download, software updates, service reports.

E: Home button: Used to navigate to the Home page.

F: Alarm button: Used to navigate to the Alarm page. It also allows the user to silence the alarm bell, hence the small “no speaker” symbol in the upper right corner of the button.

G: Config button: Used to navigate to the Configuration page.

H: History button: Used to navigate to the History page.

I: Crank 1 button: Used to manually crank the starter from battery 1 while in “HAND” mode.

J: Crank 2 button: Used to manually crank the starter from battery 2 while in “HAND” mode.

K: Stop button: Used to stop the engine if all starting conditions are gone.

L: Run Test button: Used to start the manual run test. Be aware that water will flow through the drain during the test.

M: Contextual navigation pad: Used to facilitate the navigation on specific pages. A small icon representing the

contextual navigation pad will appear at the bottom right corner of a page if the pad is active. By clicking on the small pad icon, a menu explaining the specific functions of the arrows will appear. For example, it is possible to switch between the graphical or the table mode on the logs page, as well as navigate through the tables or the help pages.

N: Help button : The help button is context sensitive It will always show the specific help page linked to the actual ViZiTouch page that was selected when the button was pressed.

O: RS-485 connector

P: CAN bus connector to IO cards

Q: USB 2.0 connector

R: Ethernet connector

S: K-Type Thermocouple connector

T: Alarm Bell connector

Alarm bell

The alarm bell is activated under default condition and under optional or user defined conditions.

Any of these conditions will energize the alarm bell but may be silenced, except in some cases, by pressing on the “Alarms / silence” membrane button. When silenced, the alarm bell restarts ringing if a new default occurs or if the alarm conditions remain unchanged after 24 hours. The alarm bell automatically stops ringing if alarm conditions are not present anymore.

Note: other external conditions may trigger optional conditions depending of the factory settings. Verify drawings affixed inside the cabinet.

Default Conditions :

- Engine Overspeed
- Engine Low Oil Pressure
- Engine High Coolant Temperature
- Engine Fail to Start
- Battery Failure 1-2
- System Overpressure
- Engine Fuel Injection Malfunction
- DC Failure
- IO Cards Communication Loss
- CAN System Failure
- File System Failure

First Setup

CONTROLLER NOT CONFIGURED!

Batt 1	...V
	...A
Batt 2	...V
	...A
AC	...
Pres.	...
Cut-In	...

WARNING: AUTOMATIC mode is DISABLED until setup is completed!

Go to Setup

Done


The first Setup must be done prior to using the controller. Completing the First Setup is the only way to access the homepage and enable the automatic mode of the controller. The complete procedure can be found in the “Quick Start-Up Guide” that is available with the controller.

Home



Home (Membrane button)

Home



The home page displays all controller statuses and important values of the controller. All voltages, currents, pressure, engine state and status, as well as all timers and cranking sequences.

The entire background will become red if an alarm becomes active. This feature will help the user identify a problem even at a significant distance away from the controller.

A: Navigation bar which contains general information about:

- The language (the language may be changed by pressing on it)
- The page title
- The alarm banner (warning and alarm messages may be shown)
- The date and time (adjustable in the Configuration page)
- The temperature. It can be changed to Celsius or Fahrenheit by pressing on it.

B: The battery charger state. It may become one of three colors and also explicitly describes the current battery charger state.

POWER UP – Green
BULK – Green
OVER_CHARGE – Green
FLOAT – Green
CHARGER_FAIL – Red
NO_AC – Red
BATTERY_FAIL – Green

An orange rectangle between the battery and the charger will appear periodically. It is the boost mode. This charging modes enables the boost function on the charger, allowing a shorter charging time of the battery. Also, it

allows the controller to detect a missing battery, and/or a problem with the charger.

C: The battery. The battery will be red if it is in failure and green otherwise. The first line of data shows the actual voltage of the battery in volts and the second line shows the actual current in amperage.

D: The engine start contactor. It will be either open or close. When closed, the color of the contactor will be green, showing that the contactor is active.

E: The starter gear. It represents the actual step of the cranking sequence. The counter inside indicates the step timer, ranging from 15 to 0 seconds. As there are two cranking modes, “waiting for crank” and “cranking”, the gear will alternate between yellow and green, allowing the user to know exactly the state of the cranking sequence. Between the two contactors, a timer is visible. It indicates the current step inside the cranking sequence. It will stay on a step during the 15 seconds of wait and on the 15 seconds of cranking and then will count on until the sixth step, which is the end of the cranking sequence.

F: The diesel engine. It will be grey if the engine is stopped, green if an “Engine Run” signal is detected and red if a “Fail to start” occurred, after 6 unsuccessful cranking attempts. Pressing on the engine will redirect the user to the “Last Service Statistics” page, which monitors all relevant statistics concerning the controller since the last service. Inside the engine two major alarms are represented; the “low oil pressure” alarm and the “engine high temperature” alarm. These alarms will stop the engine only if it is running in test mode. When active, the appropriate alarm symbol will light up, clearly indicating that the engine has a problem.

G: Three alternating square images representing three theoretical speeds to help understand the actual speed of the engine. The grey gauge shows the needle at zero RPM when the engine is stopped, the green gauge shows the set engine speed when it is running and the orange gauge shows the needle in the danger zone, representing the overspeed alarm. Please note that you need to set the HOA selector switch at the “OFF” position in order to reset the overspeed alarm. If the RPM meter option is enabled, a digital RPM counter will appear above these images, to allow a precise reading of the actual RPM of the engine.

H: The “Fuel solenoid valve” that controls the flow of fuel in the engine. When the fuel solenoid is activated, the valve will be horizontal, green and the yellow representation of the fuel will flow through the entire pipe. When the “Stop Solenoid valve” is activated, the valve will rotate vertically, become red and the yellow representation of the fuel will stop at the valve, indicating that the fuel does not flow through anymore.

I: Representation of the motor starting or stopping cause. A green capsule will indicate the reason why the motor is running. Possible choices are:

LOCAL – This start cause is triggered if the engine is locally started directly from its own control panel and the option is enabled.

MANUAL – It receives a manual crank request from one or both of the manual crank membrane buttons while the selector switch is the “HAND” position.

REMOTE MANUAL: Manual engine starting activated by a remote start contact.

DELUGE: Automatic engine starting activated by a deluge valve.

AUTO: Automatic engine starting activated by pressure drop.

REMOTE AUTO: Automatic motor starting activated by remote equipment

FLOW: Automatic motor starting activated by a signal in the FLOW/ZONE START/STOP input.

HIGH ZONE: Automatic motor starting activated by a signal in the FLOW/ZONE START/STOP input.

WEEK TEST: Automatic motor starting activated by a scheduled test.

MANUAL TEST: Automatic motor starting activated by the run test pushbutton.

AC FAIL – AC Fail will count the time following an AC Failure and at the end of a predetermined timer, will start the engine with an AC FAIL request.

A red capsule will indicate the reason why the motor is not running despite the fact that a request is being made. Possible choices are:

OVERSPEED– This start cause happens when the controller receives a request to start, but the engines sends an “Overspeed” signal, thus preventing its ability to effectively start the engine.

FAILSTART – This start cause happens when the controller receives a request to start, but a “Fail To Start” alarm is active after a cranking sequence failure, thus preventing its ability to effectively start the engine.

LOW ZONE: A not running lower zone controller prevents the motor from running. This functionality is optional.

LOCKED: An interlock signal is preventing the motor from running.

J: The discharge pressure gauge. It allows for a precise reading of the actual system pressure. The red box on the upper left corner of the gauge indicates the value of the Cut-In set point and the green box on the upper right corner represents the Cut-Out set point. These values will also be represented by a red and green line on the gage, allowing a quick comparison between the actual pressure and the set points. At the bottom of the gauge, a digital indicator shows the actual discharge pressure represented also by the needle of the gauge. Just right of the digital pressure indicator, the actual pressure unit is shown. Finally, the maximum allowable pressure is also indicated on the gauge and will scale the gauge accordingly. The discharge pressure gauge is also a button linking to the “Gauge” page, where all active gauges are displayed.

The dashboard

K: The HOA Selector switch. The three positions indicate the actual position of the HOA, “HAND” for manual mode, “OFF” and “AUTO” for automatic mode. The controller should always be left in the “AUTO” position.

L: Operations timers including the sequential start timer, the run period shutdown timer, the manual test timer, the weekly test timer and the AC Fail timer.


M: An “AC” pilot light. It represents the condition of the AC power source. The light will be green if AC power is available and will become red if an AC failure is present. If the AC fail start option is active, the AC fail start timer will appear right next of the AC pilot lamp.

N: This symbol appears when the membrane Stop push button is deactivated because of an active request. The only way to stop the engine when this appears is to put the HOA in the OFF position.

O: The alarm/warning notification.

Warning indicator: Exclamation mark in a yellow round icon. If no alarm is in ACTIVE condition on the controller and at least one warning is ACTIVE, the warning indicator will be present.

P: Displays three statuses that describe the primary configuration of the controller: Pressure actuated or Non-pressure Actuated, Automatic Controller or Non-automatic, Manual or Automatic Shutdown.



All active gauges are gathered here (ex: pressure, flow and tachometer). The discharge pressure gauge on the "Home" page must be clicked to access this page and more than 1 sensor must be installed. Clicking on the gauges will redirect to the corresponding sensor page in the advanced configuration pages. To return to the "Home" page, simply press the "Home" membrane button.

Screen Saver

The screen saver appears after a programmable amount of time set on one of the "Factory Settings" page. Its goal is to expand the lifetime of the LCD screen. The screen saver will be instantly deactivated if the engine is running or if an alarm is activated. To manually deactivate it, simply touch the screen or any membrane button. After deactivation, the screen saver will always redirect to the "Home" page. It will also log off any user by resetting the security level to 0.

Alarms



Alarms (Membrane button)

Alarms

Date	Time	Alarm	State
------	------	-------	-------

Reset Bell Test

Displays the list of currently active and occurred alarms. An alarm is called ACTIVE when its triggering condition is present. An alarm is called OCCURED when its triggering condition has been active, but is no longer true. Alarms with an "*" symbol must be reset by turning the Main Selector switch to the "OFF" position. Alarms representing serious concerns are RED. Alarms representing simple warnings are YELLOW. To silence the bell press the ALARM button or it will silence itself after the expiration of a factory set timer. Pressing on the RESET button will reset OCCURED alarms only.

The bell test button will activate the alarm bell for 3 seconds.

The table displays system events:

- Date and Time: Date and time stamp of the alarm in the YYYY.MM.DD format
- Message: Alarm message
- State: OCCURED or ACTIVE
- Color Code:
 - Red: The event is an alarm
 - Yellow: The event is a warning

Complete list of alarms :

Common Alarms:

Engine Trouble: The Engine Trouble common alarm is active when one or more of these conditions are active :

- Engine High Coolant Temperature (5)
- Engine Low Coolant Temperature (312)
- Engine Low Oil Pressure (4)
- Engine Fail to Start
- Engine Fail when Running

- Engine Overspeed* (3)
- Engine ECM Selector Switch in Alternate Position (301)
- Engine ECM Fault (304)
- Engine Fuel Injection Malfunction (302)
- PLD Low Suction Pressure (305)
- High Raw Water Temperature (310)
- Low Raw Water Flow (311)
- Battery Failure 1-2
- DC Failure
- Over Pressure

Pump Room Trouble: A common alarm activated when the following events occur:

- Fuel Tank Leak
- Low Fuel Level
- High Fuel Level
- AC Failure
- Low Pump Room Temperature
- Low Suction Pressure
- Water Reservoir Low
- Water Reservoir Empty

CTRL Trouble: Important: this relay is normally energized when controller is in normal condition. The relay is de-energized when controller trouble is detected (fail safe). The controller trouble common alarm is active when one or more of these conditions are active :

- Charger Failure 1-2
- DC failure
- Default Solenoid Valve
- Cut-In not reached during test

- AC Failure: Monitors the AC power and activates on a failure.
- Battery 1-2 Fail: Monitors the status of battery 1 and activates on a failure. This occurs when the battery is disconnected, is the wrong type or is unable to be recharged. When disconnecting a battery, there will be a delay before the alarm is activated. The boost signal will be active a minute later, or more if a ghost current is detected. If there is no response from the battery, it will execute a second test 30 seconds later, and then activate the battery failure alarm.
- Charger 1-2 Fail: Monitors the state of battery charger 1 and activates on a failure. This occurs when the battery charger has a defect, is not properly powered, or is unable to provide the needed current. It will also change to Boost Fault mode if during a boost test, the voltage does not rise. A NC dry contact is also connected from the charger to the IO Board. If this contact opens for 1 minute, the alarm will be activated.
- DC Failure: Activates if both batteries are in failure and will prevent the engine from starting.
- Service Required: Activates when service is due for the controller. This occurs when the date set in the service page has passed, or if no service has ever been done.
- Weak Battery 1-2: Activates if the battery voltage falls below the weak battery set point in the factory settings page.
- Loss of Continuity 1-2: Activates if the engine start contactors are disconnected from the controller.
- Low Pump Room Temp: Activates if the optional programmable input "Low Pump Room Temp" is activated by an external signal.
- Low Spare Temperature: Activates if the analog readout of the spare temperature input is enabled and is lower than the low spare temperature set point in the "Spare temperature" sensor page.

- WT CI Not Reached: Activates if the Cut-In is not reached during a manual run test or a weekly test timer. At the end of the 255s timer, if the Cut-In is not reached, the test may still be successful at starting the engine if the pressure has dropped by at least 5 PSI.
- WT Check WT Solenoid: Activates if the pressure does not drop a minimum of 5 PSI during the manual run test or the weekly test. Indicates a failure with the Test Solenoid Valve.
- PT fault detected: If an optional dual pressure sensor is installed, it will be activated if the two pressure transducers show different readings. Further investigation is advised to determine what caused the different readings. Note that the controller will always choose the lowest pressure reading to determine the actual system pressure. Also, if the voltage powering the transducer is below 0.5V or over 4.5V the alarm will be activated.
- Overpressure: Activates if the analog readout of the discharge pressure goes higher than the overpressure set point in the discharge pressure sensor page.
- Underpressure: Activates if the analog readout of the discharge pressure goes lower than the "Under Pressure" set point in the discharge pressure sensor page.
- Low Suction Pressure: Activates if the analog readout of the suction pressure is enabled and goes lower than the low suction pressure set point in the suction pressure sensor page.
- Force start on flow: Activates if an external contact triggers flow switch input or if the analog readout of the flow is enabled and goes higher than the flow force start on flow set point in the flow sensor page.
- Water Res. Low: Activates if the "Water Reservoir Low" contact input is triggered or if the analog readout of the water reservoir is enabled and is lower than the water reservoir low set point in the "Water Level" sensor page.
- Water Res. Empty: Activates if an external contact triggers the optional "Water Reservoir Empty" input.
- Main Relief Valve Open: Activates if an external contact triggers the optional "Main Relief Valve Open" input.
- Fuel Tank Leak: Activates if the "Fuel Tank Leak" contact input is triggered,
- Low Fuel Level: Activates if the "Low Fuel Level" contact input is triggered or if the analog readout of the fuel level is enabled and goes lower than the low fuel level set point in the "Fuel Level" sensor page.
- High Fuel Level: Activates if the "High Fuel Level" contact input is triggered or if the analog readout of the fuel level is enabled and goes higher than the high fuel level set point in the "Fuel Level" sensor page.
- Engine Fail When Running: Activates if the "Engine Run" signal is lost while the engine is running. The engine will try to start the cranking sequence once again if the starting causes are not back to normal.
- Engine Fail to Start: Activates if the engine fail to start after the complete 6 attempts crank sequence. The engine will turn red.
- Engine ECM: Activates if the specific "ECM" input is triggered on the engine connector strip.
- Engine ECM Warning: Activates if the specific "ECM" input is triggered on the engine connector strip.
- Engine ECM Fault: Activates if the specific "ECM" input is triggered on the engine connector strip.
- Engine FIM: Activates if the specific "FIM" input is triggered on the engine connector strip.
- Engine PLD Low Suction Pressure: Activates if the specific "305" input is triggered on the engine connector strip.

- Engine High Raw Water Temperature: Activates if the specific “310” input is triggered on the engine connector strip.
- Engine Low Raw Water Flow: Activates if the specific “311” input is triggered on the engine connector strip.
- Engine High Temperature: Activates if the specific “High Temp” input is triggered on the engine connector strip and the engine is running. A 3 hour timer will start when the engine stops, and if the condition is still present, the alarm will be activated. This alarm will stop the engine only if triggered during a manual run test or a weekly test.
- Engine Low Temperature: Activates if the specific “Low Temp” input (312) is triggered on the engine connector strip.
- Engine Low Oil Pressure: Activates if the specific “Low Oil Pressure” input is triggered on the engine connector strip and the engine is running. This alarm will stop the engine only if triggered during a manual run test or a weekly test.
- Engine Overspeed*: Activates if the specific “Overspeed” input is triggered on the engine connector strip and the engine is running. This alarm will immediately stop the engine and cannot be reset by using the reset button on the alarm page. The alarm must be reset on the engine itself and the controller must be turned off and on to complete the reset procedure for this alarm.
- Io_expX-inX alarm: Activates if the specific expansion programmable input on the specific expansion board is activated and triggered.
- Charger1-2 Comm. Loss.: Activates if the communication with the specific battery charger is lost.
- Battery1-2 Overvoltage: Activates if the voltage of the specific battery is higher than the specified overvoltage set point.
- High Water Level: Activates if the optional “High Water Level” contact input is triggered or if the analog readout of the water level is enabled and goes higher than the “High Water Level” set point in the “Water_Level” sensor page.
- Low ambient temperature: Activates when the ambient temperature is below the factory set value (5 Celsius).
- High ambient temperature: Activates when the ambient temperature is above the factory set value (40 Celsius).
- IO Diesel Communication Error: Activates if no communication with the diesel IO board could be established for 15 seconds. This alarm is critical and triggers the bell. If this alarm persists for more than 1 minute the controller will reboot to try and fix the problem.
- IO Expansion Communication Error: Activates if no communication with the Expansion IO board could be established for 15 seconds.
- Communication System Failure: Activates when the communication task has stopped responding. This alarm condition is critical and will be followed by a controller reboot to try and fix the problem.
- File System Failure: Activates when a file system error is detected. This alarm condition is critical and will be followed by a controller reboot to try and fix the problem.
- Pump on demand: Activates when the pressure is below the cut-in set-point on an automatic pressure actuated controller.

Configuration



Config (Membrane button)

Config

Setup all basic configuration parameters.

The main configuration page provides a quick means of changing the most common settings. The padlock icon indicates the current authorization level. A locked padlock indicates that only basic settings can be changed. Press on the padlock to enter an authorization code to unlock additional settings. An unlocked padlock showing an authorization number indicates that some settings are unlocked. Press on the padlock again when you have concluded your operation.

Access Level 0:

-The “Advanced” button activates the advanced configuration pages.

- Date and Time adjustment are accessed by pressing the clock. Refer to the “Date and Time” page for more information.

Access Level 1:

Inside the left box, the main pressure parameters can be set.

- Adjustment of the pressure reading “Unit of measure”: PSI, kPa, bar, FoH, mH2O
- Maximum pressure of system (between the Cut-Out value and 9999)
- Cut-Out adjustment (between the Cut-Out value and the Maximum Pressure value). It should be set before setting the Cut-In
- Cut-In adjustment (between 0 and the Cut-Out value)

Inside the middle box, the parameters linked to the different tests can be set. To activate the weekly test, press the white square at the left of the weekly test frequency. When activated, the square turns green. The “Weekly Test Frequency” is the text field just right of the activation square button. By clicking on it, a selection Pad will provide three choices for the frequency of the periodic test: “Weekly Test”, “Bi-Weekly Test” and “Monthly Test”.

The next set of parameters is the periodic test schedule which consists of three editable fields. The first field is the day of the week and the time, in hours and minutes. Simply press the appropriate button to set these values accordingly. The next editable field located just below is the periodic test duration in minutes. The last section of the middle box is the duration of the manual “Run Test”, labelled with the “Run Test” icon button as seen on the membrane. Press the button to modify the value of the manual "Run Test" duration.

Inside the lower box, the Automatic Shutdown may be activated and the duration of the “Run Period Timer” is shown. To edit the “Run Period Timer”, refer to the “Timers” page in the advanced configuration pages.

NumPad Page

×

Description

Max

Min

Value

×

7

8

9

←

×

4

5

6

OK

1

2

3


0

.


+/-

The NumPad is activated every time the user clicks on a white square box representing a number that can be set. On top of the NumPad, the current parameter is shown. The text will flash red if the value entered is invalid and the OK button will be black, indicating that the value is out of range. The MIN and MAX show the range of values accepted for that particular parameter. The “X” button allows the user to cancel editing the value. The back arrow erases the last entered number and the “CA” button clears the whole text field. Simply click the “OK” button once the value is set.

Date and Time Page



The interface for configuring the date and time. It features a top navigation bar with four arrow buttons: double left, single left, single right, and double right. Below these is a large empty rectangular box for the month and year. To the right of this box is a close button (X). The main area is divided into two sections. On the left is a calendar grid with days of the month from 1 to 31. On the right is a clock face with two hands. Below the clock face are two square input boxes for hours (10) and minutes (25). A 'Save' button is located at the bottom right of the interface.



A dialog box titled 'Confirm changes'. The main text inside reads: 'WARNING: Changing the date and time will affect the LOGs chronology. Are you sure you want to commit your changes?'. At the bottom right, there are two buttons: 'Cancel' and 'Save'.

The Date and Time can be configured by selecting the current month and year by pressing the arrow buttons on each side of the “Month-Year” display and selecting the day of the month by selecting the actual day. The time is set by pressing the two square boxes under the clock; the left sets the hours and the right sets the minutes. Press the Save button to commit the changes. A dialog box will appear to confirm the change “Date and Time”. The user may cancel the changes by pressing the “Cancel” button. Please note that changing the date and time will have an effect on the logs chronology.

User Login Page / KeyPad Page



The image shows a User Login KeyPad interface. It features a small square button with an 'X' icon in the top left corner. Below this is a long, empty rectangular text input field. Underneath the text field is a grid of buttons arranged in four rows. The first row contains buttons for digits 1 through 0. The second row contains buttons for lowercase letters q through p. The third row contains buttons for lowercase letters a through l. The fourth row contains buttons for 'Shift', lowercase letters z through m, a back arrow button with an 'X' icon, and an 'OK' button. The entire keypad is enclosed in a thin black border.

User Login KeyPad:


This page allows the user to log into a higher security level by entering a password. If the password is valid the text field will turn green and if it is invalid, the text field will turn red. A “X” button appears in the text field as soon as a character is entered, allowing for a quick erase of the written password.

If the password is invalid for a consecutive number of times, the user will be redirected to the “Service Dealer” page, allowing the user to communicate with the appropriate Service Dealer.

If the password is valid, the “Configuration” page will reload and the access security level will be shown inside the lock. To log off, click on the lock and the user security level will return to “0”

Other KeyPads:

The KeyPad is activated every time the user clicks on a grey rectangle box with white text representing a text that can be set. The “X” button allows the user to cancel editing the value. The back arrow erases the last entered character and the “CA” button clears the whole text field. Simply click the “OK” button once the value is set. This type of text field is mostly used to generate a digital text indication for a custom alarm input.



This page is the portal to all the advanced configuration parameters of the ViZiTouch.

All timers, sensors, factory settings, software update, service dealer and debug pages may be accessed simply by clicking on the appropriate buttons.

Since two of the analog inputs are using the same physical connector, only one of these can be installed at once. These analog inputs are shown in the grey box surrounded by a black dotted line. Each time one of these sensors is installed, the other will turn orange, preventing the dual installation of these sensors.

All buttons are set to security "Level 0" except "Update Program" which is set at "Level 1" security.

Details of the Advanced Configuration Page

Volt-Current Calibration

Config > Advanced > Volt Calibration – Current Calibration

The screenshot shows the 'Config > Advanced > Volt Calibration' interface. It features a table with columns for 'Main Voltage', 'AC', 'Actual', 'Desired', and a 'COMPUTE' button. The 'Main Voltage' row is for 'AC' and has an empty 'Desired' field. Below it, the 'Voltage' section has two rows for 'Battery 1' and 'Battery 2', each with an empty 'Desired' field and a 'COMPUTE' button. To the right of the table are navigation arrows: a right arrow and a left arrow with a return symbol.

This page is used to calibrate all analog voltages. The actual column shows the actual value calculated by the ViZiTouch. The “desired” column allows a level 2 user to enter the desired value read from a calibrated external device (multimeter). For the AC voltage and the 2 DC voltage, the calibration is done by entering the desired value and pressing on the “COMPUTE” buttons. The DC values must be entered with no batteries connected, to allow the calibration of the battery chargers in the “power supply” mode. To do so, simply turn CB3 and CB4 to OFF.

The screenshot shows the 'Config > Advanced > Current Calibration' interface. It is divided into two sections for 'Battery 1' and 'Battery 2'. Each section has a 'Calibration' header and a 'mA' unit indicator. For Battery 1, the actual current is 2650 mA. It has a 'ZERO' button, a 'Read' button, a text field with '2650', a less-than sign '<', another 'Read' button, a text field with '8880', and a 'COMPUTE' button. For Battery 2, the actual current is 2725 mA. It has a 'ZERO' button, a 'Read' button, a text field with '2725', a less-than sign '<', another 'Read' button, a text field with '8880', and a 'COMPUTE' button. At the bottom right, there is a small field showing '0.4'.

This page is used to calibrate all analog currents. The first number right beside the Battery 1 and Battery 2 text shows the actual current reading. First, Set the CB3 Breaker in the OFF position. This will disconnect the battery. Press the ZERO button. Then, put the CB3 breaker back in the ON position. Connect a small charge to the 6 and 11 terminals, to create a low current around 2600 mA. Enter this value in the most left field of battery 1, and press the Read button. Then, connect a bigger charge to the 6 and 11 terminals, around 8800 mA. Write the measured value in the second text field, and press the second read button. Finally, press the COMPUTE button to complete the calibration. Repeat for the second battery, linked to CB4 Breaker and terminals 8 and 11.

The small field at the lower right part of the page appears only if a level 2 user is logged in. It is the threshold, in Amps, to test if a battery is connected. This is amount the current in Amps has to rise during a boost test to

determine that the battery is connected. If a false battery failure alarms appears, it may be necessary to lower this value.

Timers Page **Config > Advanced > Timers 1-2**

Config > Advanced > Timers

Engine Starting and Stopping

Sequential Start Timer	<input type="text"/>	s
Run Period Timer	<input type="text"/>	m
Fail When Running Timer	<input type="text"/>	s

Overpressure	Timer On	<input type="text"/>	s
Underpressure	Timer On	<input type="text"/>	s
Low Suction Pressure Alarm	Timer On	<input type="text"/>	s

Config > Advanced > Timers2

<div>High Water Level Alarm</div> <div>Timer On <input type="text"/> s</div>	<div>High Fuel Level Alarm</div> <div>Timer On <input type="text"/> s</div>
<div>Low Water Level Alarm</div> <div>Timer On <input type="text"/> s</div>	<div>Low Fuel Level Alarm</div> <div>Timer On <input type="text"/> s</div>
<div>AC Failure</div> <div> <input type="checkbox"/> Enable Start Delay <input type="text"/> m </div>	<div>Low Oil Pressure</div> <div>Delay <input type="text"/> s</div>

Most common timers for fire pump control can be configured here. Note that any timer set to 0 will remove the delay in the decision process.

Access level 1:

- Engine starting and stopping:

The main timers settings are the “Sequential Start Timer” (seconds), which allows a delayed response on an automatic start request, the “Run Period Timer” (minutes), which in case of an automatic shutdown controller sets the time before the controller will stop the engine when all conditions are back to normal and the “Fail when running Timer” (seconds), which allows a delayed response to a “Fail When Running” condition. Note that this condition, when active, will recreate a starting sequence to allow the engine to go back to the running state.

- Overpressure timer on: Time delay for the activation of the overpressure alarm, if used,
- Underpressure timer on: Time delay for the activation of underpressure alarm, if used.
- Low Suction Pressure alarm timer on: Time delay for the activation of the low suction pressure alarm, if used.

- High Water/Fuel Level alarm timer on: Time delay for the activation of the high water/fuel level alarm, if used.
- Low Water/Fuel Level Alarm timer on: Time delay for the activation of the low water/fuel level alarm, if used.
- AC Failure: The AC Fail Start is an optional starting cause. When an AC Failure alarm becomes ACTIVE, the programmable Start Delay will start counting. At the end of the timer, if the AC Failure is still ACTIVE, the engine will start with an AC FAIL starting cause. If no other requests are activated, the engine will stop when the AC Failure alarm disappears. The option can be enabled/disabled in factory only.
- Low Oil Pressure alarm: Delays to buffer the "Low Oil Pressure" alarm (seconds). This delay is factory reserved and can only be changed by Tornatech Inc. (security "Level 9").

Inputs/Outputs Configuration

Config > Advanced > Inputs Selection-Configuration- Outputs Configuration

Config > Advanced > Input Selection



Field programmable Input 3

Field programmable Input 4

Field programmable Input 5

The Deluge Valve Start Signal is Normally Closed
Alarms Signals are configurable on the next page

- This page, if logged in, allows the re-assignment of 3 programmable inputs by pressing on the signal name. If the Deluge Valve signal is selected, it will be assigned as a normally closed input. Proceed with caution as this may cause the engine to start. If an alarm signal is chosen, it can be configured on the next page (Enabled, NO/NC, Audible, Importance (Alarm or Warning)). The available signals are:
- Low Fuel Level, High Fuel Level, Fuel Tank Leak
- Water Reservoir Empty, Water Reservoir Low, Water Reservoir High
- Flow Meter ON, Main Relief Valve Open
- Low Suction Pressure
- Lockout
- Remote Manual Start
- Deluge Valve Start (NC)



This page allows the configuration of alarm signals on the inputs, and outputs relay signals. Two buttons located far right navigates between the input and output section of the page.

Input:

The input page has four elements: The NO/NC setting, the “Digital Text Indication” field, the “Alarm Bell Icon” and the “Alarm Icon”. Each one can be enabled or disabled. The first step is to click on the square button beside the text field to activate the management of the input signal. If the “Alarm Bell Icon” is enabled, the input signal will trigger the Alarm Bell. If the “Alarm Icon” is enabled, the input signal will be treated as an alarm, if not, as a warning. As on the output page, the buttons at the top allow for an easy navigation between all available inputs of the diesel board.

Output:

The configuration is performed by pressing on the square box located beside one of the signal needed. The box will swap between BLANK (none), a NO (normally open) and a NC (normally close) symbol, allowing the desired configuration to be obtained. The final state of the output signal is a logical “OR” combination of all selected signal.

This page allows the configuration of both programmable inputs and outputs available on an IO Expansion board.. Two buttons located far right navigates between the input and output section of the page.

Input:

The input page has three elements: the “Digital Text Indication” field, the “Alarm Bell Icon” and the “Alarm Icon”. Each one can be enabled or disabled. The first step is to click on the square button beside the text field to activate the management of the input signal. Then, clicking on the text field will bring up the KeyPad, making it easy to write a custom digital text indication. A maximum of 20 characters is allowed. Refer to the KeyPad help page for more information. If the “Alarm Bell Icon” is enabled, the input signal will trigger the Alarm Bell. If the “Alarm Icon” is enabled, the input signal will be treated as an alarm, if not, as a warning..

Output:

The configuration is performed by pressing on the square box located beside one of the signal needed. The box will swap between BLANK (none), a NO (normally open) and a NC (normally close) symbol, allowing the desired configuration to be obtained. On top of all outputs signals available, it is possible to link in the same way the expansion board inputs to the selected output in any combination. The final state of the output signal is a logical “OR” combination of all selected signal.

Update Program Page



This procedure is highly important and must be attempted with care. Please make sure to contact the factory prior to using the Update Software function.


To ensure the program update is successful:

- Make sure the USB Device is plugged in at all times during the procedure.
- Do not power off the ViZiTouch while updating the software.
- Make sure the procedure is complete before removing the USB device. The ViZiTouch will reboot automatically.









All active logs, data and configuration will not be affected by software updates. Usual operation of the controller will resume as soon as the software update is completed.

Factory Settings





Config > Advanced > Factory Settings 1-2-3-4-5



Config > Advanced > Factory Settings2

Weak Battery 1 <input type="checkbox"/> Enable <input type="checkbox"/>  <input type="text"/> V <input type="checkbox"/> 	Pressure Line Fail <input type="checkbox"/> Enable <input type="checkbox"/>  <input type="text"/> PSI <input type="checkbox"/> 
Weak Battery 2 <input type="checkbox"/> Enable <input type="checkbox"/>  <input type="text"/> V <input type="checkbox"/> 	Engine Low Coolant Temp. <input type="checkbox"/> Enable <input type="checkbox"/>  <input type="text"/> s <input type="checkbox"/> 

Config > Advanced > Factory Settings3

Local Request Detection <input type="checkbox"/> Enable <input type="text"/> s	ECM Warning (303) <input type="checkbox"/> Enable <input type="checkbox"/>  <input type="text"/> s <input type="checkbox"/> 
Test Mode <input type="checkbox"/> Enable <input type="text"/> <input type="text"/>	ECM Fault (304) <input type="checkbox"/> Enable <input type="checkbox"/>  <input type="text"/> s <input type="checkbox"/> 

Config > Advanced > Factory Settings4

High Zone Enable Delay	<input type="text"/> s
Low Zone Request Maintain	<input type="text"/> s
LCD Dim Timer	<input type="text"/> s
LCD Off Timer	<input type="text"/> s
Low Ambient Temperature	<input type="text"/> C
High Ambient Temperature	<input type="text"/> C

Config > Advanced > Factory Settings 5

ip address:

subNet mask:

◀

⏮

The factory settings are always pre-configured at the factory and set the main parameters of the controller.

Left Section:

Automatic Controller – Non-Automatic Controller: An automatic controller will respond to automatic start requests, like a pressure transducer, a pressure switch, a deluge valve or a remote automatic start trigger. A non-automatic controller will only start the engine on manual requests.

Pressure Actuated – Non-Pressure Actuated: A pressure actuated controller has at least one pressure transducer installed and will monitor the system pressure at all time. In an automatic controller, the pressure drop will trigger a starting sequence of the engine automatically. A non-pressure actuated controller is equipped with a pressure switch only.

2VIZ004 – 2VIZ016: These refer to older version of the IO Diesel Board. If the controller hosts one of these version, the corresponding check box must be activated.

“Reset to Factory Settings”: This button redirects to the “Reset to Factory Settings” page. This is a major operation that must be used with care and only if the factory was contacted first. See the “Reset to Factory Settings” help for more details.

Right Section:

The first two settings set the nominal AC and DC voltage for the controller.

The following section enables the “Engine RPM” counter. The connection must be made with the engine’s magnetic pickup using the “U” terminal on the GPD - IO board. If enabled, the “Teeth” parameter must be set according to the exact number of “teeth” on the magnetic pickup gear. This parameter will allow the ViZiTouch to calculate precisely the engine actual RPM with a fast refresh rate. The value will be shown in the upper-right corner of the homepage, over the symbolic “RPM” image. This is the only setting available to a “Level 1” user on the “Factory Settings” page.

Technical information about the controller: Serial Number, Battery Charger Type, Model Name and Software Revision.

Additional optional factory parameters: Most parameters defined here share the same type of configuration. The “Bell” icon, if activated, will trigger the alarm bell and the “alarm” icon, if activated will define this signal as an alarm, otherwise, it will be identified as a warning only.

The “Weak Battery 1-2 Voltage” settings are configured to take action upon analysis of the battery 1-2 voltage. It will trigger an alarm/warning if the voltage read is lower than the value set.

The “Engine Low Coolant Temperature (312)” settings are configured to take action when the “312” terminal is used for electronic diesel engines that uses this signal. It will trigger an alarm/warning at the end of the programmable timer if enabled.

Additional optional factory parameters

The optional “Local Request Detection” can be Enabled/Disabled here, as the programmable delay used to trigger the detection. The delay sets the time before the ViZiTouch detects a “LOCAL” request. The “Local” request is defined by an active “Engine Run” input on the engine terminal strip “U” while no request was detected. In other words the engine was started locally on the engine control panel itself, without any request made by the ViZiTouch.

ECM Warning (303): Settings are configured to take action when the “303” terminal is used for electronic diesel engines that use this signal. It will trigger an alarm/warning at the end of the programmable timer if enabled.

ECM Fault (304): Settings are configured to take action when the “304” terminal is used for electronic diesel engines that use this signal. It will trigger an alarm/warning at the end of the programmable timer if enabled.

Higher Zone Enable Delay: Delay, in seconds, after which a motor run signal is sent to a higher zone controller. This option is only used for controllers in series.

Lower zone Request Maintain: Delay, in seconds, for which a run demand to a lower zone controller is maintained after all run causes has return to normal. This option is only used for controllers in series.

LCD Backlight Dim Timer: The inactivity time it takes for the ViZiTouch screen to start fading out. This is done to preserve the durability of the screen’s backlight. It is factory programmed to 5 minutes.

LCD Backlight Turn Off Timer: The inactivity time it takes for the ViZiTouch screen to turn off completely. It is factory programmed to 5 minutes.

The inactivity timer starts if no “user actions” are detected on the screen or the membrane, the engine is not running and no alarms are “ACTIVE”. As soon as one of those conditions is met, the inactivity timer will reset.

Low Ambient Temperature: Set-point for the low ambient temperature alarm.

High Ambient Temperature: Set-point for the high ambient temperature alarm.

The last page is the configuration for the MODBUS communication. The 2 fields allow the configuration of the Ip address of the ViziTouch and his subnet mask.

Reset to Factory Settings Page

Config > Advanced > Factory Settings > Factory Reset

<input type="checkbox"/> Logs	<input type="checkbox"/> Factory Settings
<input type="checkbox"/> Delete	<input type="checkbox"/> Additional Settings
<input type="checkbox"/> Pump Curves	<input type="checkbox"/> Last Saved Settings
<input type="checkbox"/> User Statistics	
<input type="checkbox"/> Factory Statistics	
<input type="checkbox"/> Service Done	

Reset Cancel

This page will reset the ViZiTouch to the original factory configuration, thus clearing all subsequent configurations performed during the life of the controller.

This procedure should only be used as a last attempt to bring back the controller to a usable state.

User “Level 2”:

The “RESET” button will be activated (will become blue) only if no square buttons from the left column are activated and the “Last Saved Settings” from the right column is not activated as well. A “Level 2” user can only reset the “Factory Settings” and/or the “Additional Settings” from the right column.

The “Factory Settings” reset will restore the controller to its original factory configuration and service state. This means that the first service will be undone, automatic mode settings, as well as the controller’s “Homepage” will be deactivated until “First Service” is completed again. Please refer to the “Quick Start-Up” guide for more information on how to perform the “First Start-Up” and how to complete the “Field Acceptance Test Report”.

Please note that all logs, pump curves and statistics will not be reset.

The “Additional Settings” reset will update the controller with an additional configuration sent by the manufacturer. It does not perform a true “Factory Reset”. Its purpose is to allow an update of configuration variables that can only be updated by Tornatech Inc.

All other square buttons on this page are “Level 9” security and can only be used by certified Tornatech representatives, unless otherwise specified. The first square in the upper left corner performs the “Select all” function for these parameters.

The screenshot shows a web interface for the 'Service' page. At the top, a breadcrumb trail reads 'Config > Advanced > Service'. The main content area is divided into two columns. The left column contains a large box for 'Company Name' with a placeholder image, and below it, a section for contact information including 'Contact Name', 'Phone number #1', 'Phone number #2', and 'email address'. The right column features a 'Last Pump Curve' section with a 'NEW' button. At the bottom, there is a 'Service Done' button, a date/time input field labeled 'Last Done:' followed by a plus sign, a small input box, an equals sign, and another date/time input field labeled 'Next On:'. A back arrow button is located at the bottom right.

The upper left section hosts the Tornatech Inc. business card by default. This image can be changed by the service dealer to incorporate a customized image. The image must have been created by Tornatech Inc., sent to the service dealer and copied on a USB Device. The “Level 1” user can update the image by pressing the Tornatech logo when the USB Device containing the business card is inserted into the USB port. Please contact factory for more details.

The box situated just right of the business card is related to the “Pump Curve”. The ViZiTouch allows for the recording of up to 10 different pump curves. The date and time of the last pump curve recorded is displayed here. The “NEW” button allows the user to record a new pump curve. Clicking this button will redirect the user to the “New Pump Curve” page. See the “New Pump Curve” help section for more details on how to record a new pump curve.

The user can see both the date of the last service done and the date of the next service at the bottom of the screen.

Access level 1:

- Change the period before the next service is required by pressing the white box between the “Last Done” date and the “Next On” date. The “Next On” date will be adjusted automatically depending on the period selected and the date of the last service.

When the required service is done, the user must click on the “Service Done” button to commit and end the service.

Config > Advanced > Service > New Pump Curve

Pdis - Psuc = Pnet Flow Volt Current

1							▲
2							
3							
4							
5							
							▼

Reset Auto Save ↩

The Service Dealer “New Pump Curve” Procedure

This page allows the user to create a pump curve. At the bottom of the screen, there are 3 buttons:

- Reset: Clears the data of the pump curve in progress.
- Auto: Uses needed types of transducers to create the pump curve (Discharge pressure, Suction pressure and Flow sensor need to be installed.)
- Save: Saves the pump curve and update the pump curve chronological order as displayed in the “History > Pump Curves” page.

The first line of the legend displays the system units for every column. The second row of the legend describes the parameters represented and the third line of the legend displays the actual value of these parameters for quick reference. The scroll bar on the right of the table allows the user to move downward in the table, up to the 10th point. The new pump curve data will become invalid if the Flow or Pressure units are changed during the input procedure or if no Flow or Pressure data is entered. In that case, click on the reset button. The Save button must be used in order to record the pump curve into the ViZiTouch memory.

- Pdis: Discharge Pressure
- Psuc: Suction Pressure
- Pnet: The Net Pressure is calculated by subtracting the Suction Pressure from the Discharge Pressure. In Manual Mode, it must be entered manually.
- Flow: Flow
- Rpm: Rpm if enable or manually entered.

“Manual Mode”

To manually create a pump curve, data must first be entered on the first row and then on subsequent rows. There are a total of 10 rows available, but there is no minimum required to get a curve. Of course, more rows improve precision.

In each column the user must input every following value for maximum information, readability and future reference. It is possible to create a quick pump curve, but it is not recommended since future references might be less accurate. In that case, only fill the Pnet and the Flow values. The first row of data must set the “Flow” to 0 and the last row of data must have a Pnet of 0. These values will ensure the pump curve is fully represented on the graph, for all pressure and all flows.

When the required number of points are entered, just click on the “Save” button to record the pump curve and exit this page. You will be redirected to the “History > Pump Curve” page.

“Auto Mode”

To automatically create a pump curve, the discharge pressure, suction pressure and flow meter must all be installed on the controller.

- Click on the “Auto” button

- A series of validation will take place to ensure all data is valid.

- After a pre-defined timer, the ViZiTouch will acquire all data from all sensors and fill the first row of the pump curve table. The pressure must be stabilized before the samples are to be taken. The Pnet pressure will be calculated.

- The ViZiTouch will then ring the Alarm Bell shortly, alerting the user to drop the pressure. As soon as the pressure is stabilized once again, the ViZiTouch will take the second row of values.


- This automatic procedure will go on until the discharge pressure is near zero.

- The ViZiTouch will then take the last row of samples and stop the Automatic mode acquisition.

- At any point, it is possible to reset the recorded values and start the automatic mode sequence from the beginning.

- Click on the “Save” button to record the pump curve and exit this page. The user will be redirected to the “History > Pump Curve” page.





Automatic Pump Curve Mode Disabled



The automatic pump curve was disabled because it needs three sensors installed. The three sensors buttons link to the corresponding sensor page, allowing a quick navigation. If the button is orange, this indicates that this particular sensor is not installed. If the button is blue, it means that this particular sensor is installed. It is always possible to quit the automatic mode by pressing the "Cancel" button.

The Sensors Pages


Config > Advanced > Discharge Pressure

Sensor		Alarms	
<div>PT1</div>		<input type="checkbox"/> Over Pressure	
Calib.	<input type="text"/>	<input type="checkbox"/> 	SET <input type="text"/>
Range	<input type="text"/> <input type="text"/>	<input type="checkbox"/> 	RESET <input type="text"/>
<div>Apply</div>		<input type="checkbox"/> Under Pressure	
		<input type="checkbox"/> 	SET <input type="text"/>
		<input type="checkbox"/> 	RESET <input type="text"/>



Calibration

Read < Read

COMPUTE




Config > Advanced > Suction Pressure

Sensor		Alarms	
<input type="checkbox"/> Installed		<input type="checkbox"/> Low Suction Pressure	
Calib.	<input type="text"/>	<input type="checkbox"/> 	SET <input type="text"/>
Range	<input type="text"/> <input type="text"/>	<input type="checkbox"/> 	RESET <input type="text"/>
<div>Apply</div>			





Calibration

Read < Read

COMPUTE




Config > Advanced > Water Level

Sensor		Alarms			
<input type="checkbox"/> Installed		<input type="checkbox"/> High Water Level			
Calib.	<input type="text"/>	<input type="checkbox"/> 	SET <input type="text"/>	DRY <input type="checkbox"/>	
Range	<input type="text"/> <input type="text"/>	<input type="checkbox"/> 	RESET <input type="text"/>		
<div>Apply</div>		<input type="checkbox"/> Water Reservoir Low			
		<input type="checkbox"/> 	SET <input type="text"/>	DRY <input type="checkbox"/>	
		<input type="checkbox"/> 	RESET <input type="text"/>		

Calibration

Read < Read

COMPUTE



Config > Advanced > Flow

Sensor	Alarms
<input type="checkbox"/> Installed <input type="text"/> Calib. <input type="text"/> Range <input type="text"/> <input type="text"/> <input type="button" value="Apply"/>	<input type="checkbox"/> Force Start on Flow <div> <input type="checkbox"/> SET <input type="text"/> DRY </div> <div> <input type="checkbox"/> RESET <input type="text"/> <input type="checkbox"/> </div>

Calibration

<

Config > Advanced > Spare Temperature

Sensor	Alarms
<input type="checkbox"/> Installed <input type="text"/> Calib. <input type="text"/> Range <input type="text"/> <input type="text"/> <input type="button" value="Apply"/>	<input type="checkbox"/> Low Spare Temp. <div> <input type="checkbox"/> SET <input type="text"/> </div> <div> <input type="checkbox"/> RESET <input type="text"/> </div>

Calibration

<

Config > Advanced > Fuel Level

Sensor	Alarms
<input type="checkbox"/> Installed <input type="text"/> Calib. <input type="text"/> Range <input type="text"/> <input type="text"/> <input type="button" value="Apply"/>	<div> <input type="checkbox"/> High Fuel Level <div> <input type="checkbox"/> SET <input type="text"/> DRY </div> <div> <input type="checkbox"/> RESET <input type="text"/> <input type="checkbox"/> </div> </div> <div> <input type="checkbox"/> Low Fuel Level <div> <input type="checkbox"/> SET <input type="text"/> DRY </div> <div> <input type="checkbox"/> RESET <input type="text"/> <input type="checkbox"/> </div> </div>

Calibration

<

In the ViZiTouch, all sensors refer to analog input connectors on the I/O board. They all have similar settings and configuration.

The “Installed” selection (“Level 2” security): Install or uninstall this sensor from the ViZiTouch configuration.

Discharge Pressure: To set the pressure system unit, go the “Config” page. All pressure transducers share the same unit.

The “Source” button (4 choices): (“Level 2” security)

- None: No pressure transducer or pressure switch is installed
- PT1 (factory standard): Only the AI1 terminal on the “T” terminal strip is enabled.
- PT2: Only the AI2 terminal on the “T” terminal strip is enabled.
- AUTO (factory installed option): AI1 and AI2 are installed and arranged for a redundancy system. The ViZiTouch will always consider the lowest of the two pressure values as the reference. Additional alarms, like “PT fault detected” become enabled. This alarm is triggered when the two transducers provides values that are different by more than a pre-set delta value. The ViZiTouch will never make a decision as to which transducer is faulty; it will only reveal that there is a problem with one of them. The service dealer should test both transducers to find out which one is faulty.

Suction Pressure: To set the pressure system unit, go the “Config” page. All pressure transducers share the same unit.

The “suction pressure” sensor shares the same analog input (AI4) as the water level sensor. Only one of them can be installed at all time. Prior to installing one of them, the other one must be uninstalled by visiting its own sensor page.

Flow: The “Flow” sensor shares the same analog input (AI3) as the spare temperature sensor. Only one of them can be installed at all time. Prior to installing one of them, the other one must be uninstalled by visiting its own sensor page.

The “Unit” button is located just right of the “Installed” selection. Click on it to select the appropriate “Flow” Unit, the factory pre-set unit is the GPM.

Flow Start:

- Enable/Disable the “Flow Start” condition by pressing the square button. If this alarm is enabled, it will also start the engine by means of a “FLOW” request.
- Alarm Bell Icon: Activates the bell when a “Flow Start” occurs.
- Alarm Icon: If selected, the “Flow Start” event will be an alarm. If unselected, it will be a warning.
- Value: Flow value at which the “Flow Start” event will change state.
- Timer On: Timer used to buffer the activation of the “Flow Start” signal by the ViZiTouch.

Water Level: The “Water Level” sensor shares the same analog input (AI4) as the suction pressure sensor. Only one of them can be installed at all time. Prior to installing one of them, the other one must be uninstalled by visiting its own sensor page. The “Water Level” sensor has no unit, since it is monitoring the “Water Level” as a percentage.

Spare Temperature: The “Spare Temperature” sensor shares the same analog input (AI3) as the Flow sensor. Only one of them can be installed at all time. Prior to installing one of them, the other one must be uninstalled by visiting its own sensor page. The “Unit” button is located just right of the “Installed” selection. Click on it to select the appropriate “Spare Temperature” Unit, the factory pre-set unit is the Celsius.

Fuel Level (GPD Model Only): The “Fuel Level” sensor has no unit, since it is monitoring the “Fuel Level” as a percentage.

The Calibration method is the same for all sensors.

CALIBRATION:

The Calibration button: (“Level 2” security for the choice of calibration, but “Level 1” security for the calibration procedure itself.) There are 4 ways to calibrate every sensor:

- 0-10V: Theoretical calibration with 0-10V sensor. Simply enter a value in the system pressure unit for 0V and another value for 10V. Click on the "Apply" button to confirm the calibration. The resulting measured pressure is shown in the lower right corner of the "Sensor" box. Make sure the dipswitch package right below the "T" terminals is set to "0-10V" for that particular sensor (refer to the drawing). The switches are labelled and are each linked to one analog input, in this case "1 or 2". *Important Note: A set of jumpers is also associated with each analog input. **MAKE SURE THE CONTROLLER IS COMPLETELY POWERED OFF BEFORE MOVING A JUMPER. THIS INCLUDES REMOVING THE AC AND DC POWER.** The jumper can be placed on "5Vdc", "12Vdc" and "Vaux" and represents the powered DC value of the sensor. The factory pre-set position is "5Vdc". If an installed sensor has a power value of "5Vdc", then the "0-10V" theoretical calibration must be calculated accordingly. Please contact manufacturer for more information.

- 4-20mA: Theoretical calibration with 4-20mA sensor. Simply enter a value in the system pressure unit for 4mA and another value for 20mA. The procedure explained above also applies in this case.

-Field Calibration: This is the factory pre-set method and the only one that is an actual calibration. Selecting this calibration method will generate the Calibration box situated in the lowest part of the sensor page. It is very important that the same care is used when selecting the appropriate dipswitch setting and jumper position. Please refer to the "0-10V" section above.

1. Two actual points (low and high) are required
2. Set the lowest point (usually 0).
3. Press the left read button
4. Press the left rectangle text field and enter the value read on the external calibrated gauge.
5. Set a high point (usually the highest possible value will create the best calibration).
6. Press the right read button
7. Press the right rectangle text field and enter the value read on the external calibrated gauge.
8. Press the calculate button to finish the calibration. If the settings are incorrect, the calculate button will remain red and if correct, the button will turn blue. The resulting measured value is shown in the lower right corner of the "Sensor" box.

- On/Off: Use the input with a dry contact sensor, for example a float switch. The only parameter to set for this method is the NO/NC buttons, effectively selecting between a normally open and a normally close switch. Click on the "Apply" button to confirm the calibration.

The Alarms Section: ("Level 1" security)

The "DRY" button can enable or disable the "Dry Contact Input" on the IO board. There are two modes when enabled, either "Normally open, NO" or "Normally close, NC". Each mode is represented by the standard NO/NC symbols.

- Enable/Disable the corresponding alarm/warning condition by pressing the square button
- Alarm Bell Icon: Activates the bell when the condition occurs.
- Alarm Icon: If selected, the occurring condition will be an alarm. If unselected, it will be a simple warning.
- RESET: Value at which the condition will go from the "ACTIVE" state to the "OCCURRED" state.
- SET: Value at which the system will activate the corresponding condition.

Details of the Debug Page

Calibration

Config > Advanced > Debug > Calibration

Raw	Gain	Offset	Scaled
Fuel Lev			
Flow			
PT1			
PT2			
SucPress			
Water Lev.			
Spare T.			
Batt1 Volt.			
Batt2 Volt.			
Batt1 Cur.			
Batt2 Cur.			

This table displays all calibration parameters. The “Scaled” value is the final calculated value used in the ViZiTouch. It is calculated by multiplying the “Raw” value by the “Gain” coefficient and by adding the “Offset” value. This information is useful when debugging the analog inputs on the IO board.

IO Debug

Config > Advanced > Debug > IO

Factory Reserved 1	<input type="radio"/>	CTRL Trouble	<input type="radio"/>	TEST
Deluge Valve	<input type="radio"/>	Engine Run	<input type="radio"/>	TEST
Remote Automatic	<input type="radio"/>	Engine Run	<input type="radio"/>	TEST
Remote Manual	<input type="radio"/>	MainSw. in Auto	<input type="radio"/>	TEST
Factory Reserved 2	<input type="radio"/>	MainSw. H-O-A	<input type="radio"/>	TEST
Factory Reserved 3	<input type="radio"/>	Engine Trouble	<input type="radio"/>	TEST
Flow/Zone Start-Stop	<input type="radio"/>	Pump Room Alarm	<input type="radio"/>	TEST
Factory Reserved 4	<input type="radio"/>	Field Prog. Out	<input type="radio"/>	TEST
Factory Reserved 5	<input type="radio"/>	WT SV	<input type="radio"/>	TEST
Factory Reserved 6	<input type="radio"/>			

The small white circle beside each signal is a representation of its state. If the white circle is filled with a green dot, then the signal is activated. Comparing these software signals and the physical state of the signal on the electronic board is the best way to troubleshoot. In the right column, additional “TEST” buttons are located beside each output signal. Clicking on these buttons will toggle the output state of this signal, again allowing a comparison between the software and hardware state of these signals to help troubleshoot.

Config > Advanced > Debug > Exp. 1

<input type="radio"/> Installed Comm. No.: <input type="text"/>	OUT1	<input type="radio"/> TEST
IN1 <input type="radio"/>	OUT2	<input type="radio"/> TEST
IN2 <input type="radio"/>	OUT3	<input type="radio"/> TEST
IN3 <input type="radio"/>	OUT4	<input type="radio"/> TEST
IN4 <input type="radio"/>	OUT5	<input type="radio"/> TEST
IN5 <input type="radio"/>	OUT6	<input type="radio"/> TEST
IN6 <input type="radio"/>	OUT7	<input type="radio"/> TEST
IN7 <input type="radio"/>	OUT8	<input type="radio"/> TEST
IN8 <input type="radio"/>	OUT9	<input type="radio"/> TEST
	OUT10	<input type="radio"/> TEST


The small white circle beside each signal is a representation of its state. If the white circle is filled with a green dot, then the signal is activated. The first element in the left column is the indication of whether or not the optional Expansion board is installed. In the box, the corresponding Expansion board number is displayed. Comparing between these software signals and the physical state of the signal on the electronic board is the best way to troubleshoot. In the right column, additional “TEST” buttons are located beside each output signal. Clicking on these buttons will toggle the output state of this signal, again allowing a comparison between the software and hardware state of these signals to help troubleshoot.

History



History (Membrane button)

History



Select specific pages within the history section. Everything related to the statistics, events, pressure, power logs and the download to USB is available within the History page.

-Events: This button leads to the “Events” page, which displays the most recent 500 events. Each event log contains the date and time of occurrence as well as a brief description of the event.

-Download to USB Device: This button leads to the “Download to USB Device” page, which allows the user to download information, including the user manual, drawings, logs, statistics and configuration.

-First Service Statistics: This button leads to the “First Service Statistics” page, which displays all relevant statistics calculated since the very first service done on the controller.

-Last Service Statistics: This button leads to the “Last Service Statistics” page, which displays all relevant statistics calculated since the last service done on the controller.

-All Time Statistics: This button leads to the “All Time Statistics” page, which displays the date and time of the first power up, the date and time when the first start-up was completed and the total “On Time” of the controller. These statistics can never be reset.

-Pressure/Power Curves: This button leads to the “Pressure Curves” / “Power Curves” page accordingly, which displays all relevant pressure/power information.

-Pump Curves: This button leads to the “Pump Curves” page.

Details of the History Page

Events Page

History > Events Log

History > Events Log			
	Date	Time	Message
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			




It shows the last 500 events which occurred in chronological order. The first column is the date, the second one is the time of occurrence and the third column is the “Event message”. To obtain a log that is older than 500 events, visit the “Download to USB Device” page and select “Events”. This method will generate a file containing all events logs in the ViZiTouch history.

The contextual navigation pad is implemented in this page. It allows quick navigations functions, like “previous page”, “next page”, “first page” and “last page”. As always, clicking on the Navigation Pad Icon in the lower right corner of the screen will pop-up the Navigation Pad functions specific for this page.

Download to USB Device

History > Download to USB





To download information from the ViZiTouch to a USB Device a user with at least a “level 1” password must be logged in. The “Download to USB” button will execute the command. If a USB Device is not present or if there is an error, a message saying “Could not mount USB drive” will appear and any further action is cancelled. To try again, remove the device, re-insert and press the button once more.

-Archived logs: All logs files that were archived using the “Archive copied files” square button. The purpose of archiving files is to free up memory on the ViZiTouch by archiving older log files.

-Logs: All logs are currently available in the ViZiTouch memory. A “Comma Separated Values” or “.csv” file is created every day and is named accordingly. Most software in modern computers will be able to read and interpret these files. The log files contain the event logs, the pressure logs and the power logs.

-Documentation: All “.pdf” files available in the ViZiTouch, usually the complete user manual, the quick startup guide, the drawings and schematics.

-Configuration: All configuration parameters contained in a “.txt” file, including but not limited to nominal values, serial number, calibration parameters.

-Pump Curves: A “Comma Separated Values” or “.csv” file is created for every pump curve created and is named accordingly. Every column is clearly identified with a title describing the values.

-Statistics: A “.csv” file including every kind of statistics, minimum, maximum, average for pressure and temperature and all engine statistics, as well as factory data.

The Statistics

First/Last Service Statistics

History > Statistics since first/last service

History > Statistics since first service	
Since	On Time
Engine	
Last Run	
Run Time	
Start Count	
Pressure	
Minimum	
Maximum	
Average	
Temperature	
Minimum	
Maximum	
Average	

History > Statistics since last service	
Since	On Time
Engine	
Last Run	
Run Time	
Start Count	
Pressure	
Minimum	
Maximum	
Average	
Temperature	
Minimum	
Maximum	
Average	

The following descriptions apply to two pages reachable by the “First Service Statistics” and the “Last Service Statistics” button on the History page. All statistics shown here are calculated since the first/last service was done. All dates are in the YYYY.MM.DD format and all time references are in the HH:MM:SS format.

- Since: Date and time when the first/last service was done.
- On Time: Total duration of controller powered on during that period.

Engine:

- Last run: Date and time of the engine's last run.
- Run time: Total running time of the engine during that period.
- Start count: Number of times the engine started during that period.

Pressure:

- Minimum: Value of minimum pressure displayed in the system actual unit and the moment it was reached.

- Maximum: Value of maximum pressure displayed in the system actual unit and the moment it was reached.
- Average: Calculated value of average pressure displayed in the system actual unit.

Temperature:

- Minimum: Value of minimum temperature displayed in the system actual unit and the moment it was reached.
- Maximum: Value of maximum temperature displayed in the system actual unit and the moment it was reached.
- Average: Calculated value of average temperature displayed in the system actual unit.

All Time Statistics

History > All Time Statistics

History > All Time Statistics	
First Power Up	
First Start Up	
On Time	


All statistics shown here are calculated since the controller's first start-up was done. All dates are in the YYYY.MM.DD format and all time references are in the HH:MM:SS format.

- First Power Up: Date and time of when the controller was first powered up.
- First Start Up: Date and time of when the controller's first start-up was completed.
- On Time: Total duration of controller powered on since the first power-up.

Pressure Curves

Graphical Mode

History > Pressure Log Curves



The vertical axis represents the pressure in the actual unit selected. Its scale is dynamic and will resize depending on the highest recorded value. The horizontal axis represents time and period. The left part of the horizontal axis shows the beginning of the current scope and the right part shows the end of the scope. Located just right of the axis, the total scope time is shown. The contextual navigation pad can be used in this page. It allows quick navigations functions, like “Zoom in”, “Zoom out”, “Rewind”, “Forward” and “Textual Mode”. As always, clicking on the Navigation Pad Icon in the lower right corner of the screen will pop-up the Navigation Pad functions specific for this page. By pressing the right or left buttons on the navigation pad, the time will shift back or forth by the quarter of the current zoom setting, allowing a quick user-friendly navigation.

The grey vertical bar with a blue arrow, located far right of the screen, is the legend. Clicking on it will display an accurate description of the different curves (Discharge pressure, Suction pressure when available, Cut-In and Cut-Out) each with their respective colors.

Between the “0” pressure value and the horizontal axis, a short series of narrow horizontal zones are displayed. They are described in the “Indicators” section of the legend. These zones indicate when the engine was running and when a jockey pump was running by colorizing small sections of the horizontal zone whenever the condition is occurring.

As indicated earlier, the “Textual Mode” is available by pressing the “Select” button on the navigation pad. This will represents the pressure logs in a table form, allowing for a more precise reading (see “Textual Mode” right below).

Textual Mode

History > Pressure Log Text

History > Pressure Log Text										
	Date	Time	Unit	Psuc	Pdis	C.I.	C.O.	E.	JP	
1										
2										
3										
4										
5										
6										
7										
8										
9										
10										
11										

The “Pressure Log text” shows a table with 10 rows. The total number of rows available is 500 and the logs are sorted in chronological order. To see more logs, please download all logs on a USB Device.


- Description of the columns :
- Date: Date when the log was recorded
 - Time: Time when the log was recorded
 - Unit: Actual pressure unit when the log was recorded
 - Suc.: Suction pressure value
 - Dis.: Discharge pressure value
 - C.I.: Cut-In value when the log was recorded
 - C.O.: Cut-Out value when the log was recorded
 - ER: The cell will become green if the engine was running for that specific pressure log.
 - JP: The cell will become green if the jockey pump was running for that specific pressure log.

The contextual navigation pad is implemented in this page. It allows for quick navigation functions, like “Page Up”, “Page Down”, “First Page”, “Last Page” and “Graphical Mode”. As always, clicking on the Navigation Pad Icon in the lower right corner of the screen will pop-up the Navigation Pad functions specific for this page. By pressing these buttons, the displayed rows will shift, allowing a quick user-friendly navigation.

Power Curves

Graphical Mode

History > Power Log Curves



The power curve graphical mode contains two vertical axis. The first two curves, as seen on the legend, are the voltage of the two batteries. They are linked to the first axis on the left of the graph in Volt. The two last curves, as seen on the legend, are the current of the two batteries. They are linked to the second axis on the right of the graph in Ampere. The vertical axis scales are dynamic and will resize depending on the highest recorded value. The horizontal axis represents time and period. The left part of the horizontal axis shows the beginning of the current scope and the right part shows the end of the scope. Located just right of the axis, the total scope time is shown. The contextual navigation pad is implemented in this page. It allows for quick navigation functions, like “Zoom in”, “Zoom out”, “Rewind”, “Forward” and “Textual Mode”. As always, clicking on the Navigation Pad Icon in the lower right corner of the screen will activate the Navigation Pad with functions specific for the page. By pressing the right or left buttons on the navigation pad, the time will shift back or forth by a quarter of the current zoom setting, allowing a for quick user-friendly navigation.

The grey vertical bar with a blue arrow, located at the far of the screen is the legend. Clicking on it will display an accurate description of the different curves (Vbatt1, Vbatt2, Ibatt1, Ibatt2) with their respective colors.

Between the “0” voltage value and the horizontal axis, horizontal zones are displayed. They are described in the “Indicators” section of the legend. This zone indicates when the engine was running by shading small sections of the horizontal zone whenever the condition is occurring.

As indicated earlier, the “Textual Mode” is available by pressing the “Select” button on the navigation pad. This will represent the power logs in a table form, allowing for a more precise reading (see “Textual Mode” right below).


History > Power Log Text							
	Date	Time	Vbatt1	Vbatt2	lbatt1	lbatt2	E.
1							
2							
3							
4							
5							
6							
7							
8							
9							
10							
11							

The “Power Log text” shows a table with 10 rows. The total number of rows available is 500 and the logs are sorted in chronological order. To see more logs, please download all logs on a USB Device.

Description of the columns :

- Date: Date when the log was recorded
- Time: Time when the log was recorded
- Vbatt1: Actual voltage of battery charger 1
- Vbatt2: Actual voltage of battery charger 2
- lbatt1: Actual current of battery charger 1
- lbatt2: Actual current of battery charger 2
- ER: The cell will become green if the engine was running for that specific power log.

The contextual navigation pad is implemented in this page. It allows for quick navigations functions, like “Page Up”, “Page Down”, “First Page”, “Last Page” and “Graphical Mode”. As always, clicking on the Navigation Pad Icon in the lower right corner of the screen will pop-up the Navigation Pad functions specific for this page. By pressing these buttons, the displayed rows will shift, allowing a for quick user-friendly navigation.



The vertical axis represents the pressure in the actual unit selected. Its scale is dynamic and will resize depending on the highest recorded value. The horizontal axis represents the flow in the actual unit selected. Its scale is dynamic and will resize depending on the highest recorded value. The contextual navigation pad is implemented in this page. It allows quick navigations functions, like "Previous" and "Next". As always, clicking on the Navigation Pad Icon in the lower right corner of the screen will activate the Navigation Pad with functions specific to that page. By pressing the right or left buttons on the navigation pad, the pump curve displayed will change, allowing a quick user-friendly navigation.

The navigation is also represented in the elements of the upper right corner of the graph. The white square indicates the date and time when the pump curve was recorded. The two arrow buttons will select the next or the previous pump curve and the "Delete" button will delete the currently selected pump curve, if the user is at least logged in as "Level 1".

Technical Documents



Pre-field Acceptance Test

TORNATECH MODEL GPD DIESEL FIRE PUMP CONTROLLER PRE- FIELD ACCEPTANCE TEST CHECK LIST			
Note: This document should be an official indication of whether or not the installation and general condition if the equipment is adequate for a field acceptance test. This document should also aid the individual responsible for executing the field acceptance test in his decision to carry out or not the controller field acceptance test of the equipment.			
Installation Check List:		YES	NO
1	Verify that the nameplate of the Fire Pump Controller corresponds with the AC voltage available and the DC starting voltage of the engine.		
2	Visual inspection for any damage to the exterior of the Fire Pump Controller. Make sure the enclosure, alarm bell, selector switch, membrane and display are not damaged.		
3	Verify that the Fire Pump Controller has been installed within sight of the pump and engine.		
4	Verify that the Fire Pump Controller has been installed not less than 12 inches from the floor of the mechanical room.		
5	Verify that all electrical connections to the Fire Pump Controller are done using liquid tight conduit and connectors.		
6	With the Fire Pump Controller door open, visually inspect for any drill chips, dirt or foreign objects in the bottom of the enclosure, loose wires, broken components and general proper electrician workmanship.		
7	Verify that the correct AC voltage is supplied to the controller by taking a voltage reading at the L1 & N (120V) or L1 & L2 (220-240) terminals.		
8	Verify that the terminal connections between the Fire Pump Controller and the engine (1 to 11 and 12 for Caterpillar engines) are properly done (optionally 301,302,303,304,305,310,311,312).		
9	Verify that wiring to terminals #6, #8 (batteries) and #11 (ground) are of the appropriate gauge size. See label inside controller).		
10	Verify proper grounding of the Fire Pump Controller.		
Initial Power-Up Check List:		YES	NO
1	Verify selector switch is in the "OFF" position		
2	With the Fire Pump Controller door open, turn to "ON" circuit breakers CB3 and CB4 (DC) then CB1 and CB2 (AC). This sequence is very important.		
3	Close Fire Pump Controller door. Verify on the ViZiTouch Homepage that the correct battery voltage appears.		
4	Place the selector switch in the "HAND" position. Verify that no alarms are displayed on the screen.		
5	Place the selector switch in the "AUTO" position. Verify that no alarms are displayed on the screen.		
Manual and Automatic Start Check List:		YES	NO
Note: A manual or automatic start must only be executed if the engine and the pump have been cleared to be started by their respective official service technicians.			
1	Place selector switch in the "Hand" position.		
2	Verify starting of engine by pressing "Battery # 1 Manual Crank" membrane button.		
3	Stop engine by placing the selector switch to the "OFF" position.		
4	Verify starting of engine by pressing "Battery # 2 Manual Crank" membrane button.		
5	Stop engine by placing the selector switch to the "OFF" position.		
6	Set Cut-Out and Cut-In settings by following the quick start up guide or referring to the ViZiTouch documentation. You need to be logged in to modify these settings. Verify automatic start by dropping system pressure below Cut-In setting.		
7	Stop engine by pressing "Stop" pushbutton. Note: Engine will only stop if the system pressure is above the Cut-Out setting.		

Tornatech Controller S/N: _____

Installation address: _____

Check list completed? _____ Yes _____ No

Check list completed by: _____

Company: _____

Date: _____

Witnessed By: _____

Comments: _____

Field Acceptance Test Report

TORNATECH MODEL GPD DIESEL ENGINE FIRE PUMP CONTROLLER FIELD ACCEPTANCE TEST REPORT			
Note: This document is the Tornatech official Field Acceptance Test report which follows the latest NFPA 20 requirements of article 14.2.6 Controller Acceptance Test pertinent to diesel engine driven fire pump controllers. Tornatech strongly recommends that a pre-field acceptance verification (Tornatech document GPD-PREFAT-001-E Pre-Field Acceptance Test Check List) be completed before this official field acceptance test.			
Complete this first section if it was not completed during the Pre-Field Acceptance test			
Manual and Automatic Start Check List: Note: A manual or automatic start must only be executed if the engine and the pump have been cleared to be started by their respective official service technicians.		YES	NO
1	Place selector switch in the "Hand" position.		
2	Verify starting of engine by pressing "Battery # 1 Manual Crank" membrane button.		
3	Stop engine by placing the selector switch to the "OFF" position.		
4	Verify starting of engine by pressing "Battery # 2 Manual Crank" membrane button.		
5	Stop engine by placing the selector switch to the "OFF" position.		
6	Set Cut-Out and Cut-In settings by following the quick start-up guide or referring to the ViZiTouch documentation. You need to be logged in to modify these settings. Verify automatic start by dropping system pressure below Cut-In setting.		
7	Stop engine by pressing "Stop" membrane button. Note: Engine will only stop if the system pressure is above the Cut-Out setting.		
Battery # 1		YES	NO
1	3 manual starts		
2	3 automatic starts		
3	1 RUN TEST start		
4	1 remote/deluge valve start		
5	Start and Run engine at full speed after 1 crank cycle		
Battery # 2		YES	NO
1	3 manual starts		
2	3 automatic starts		
3	1 RUN TEST start		
4	1 remote/deluge valve start		
5	Start and Run engine at full speed after 1 crank cycle		

Visual/Audible Alarm Verification		YES	NO
1	<p>Battery failure:</p> <ul style="list-style-type: none"> - At the terminal strip, turn CB1 OFF, disconnect wire #6 for battery #1. Then reconnect wire 6 and put CB1 to ON. - At the terminal strip, turn CB2 OFF, disconnect wire #8 for battery #2. Then reconnect wire 8 and put CB2 to ON. - Audible and visual alarm will appear for battery failure and controller trouble <p>Note: it is important to return the wires back to their original place and reset the alarms in order to continue the tests.</p>		
2	<p>Charger failure:</p> <ul style="list-style-type: none"> - Switch either circuit breaker #1 (CB1) or circuit breaker #2 (CB2) to the OFF position to test either charger. - Audible and visual alarm will appear for charger failure and controller trouble <p>Warning: Do not switch both CB1 and CB2 off at the same time.</p> <p>Note: it is important to return the circuit breaker back to its original position and reset the alarms in order to continue the tests.</p>		
3	<p>Engine high coolant temperature:</p> <ul style="list-style-type: none"> - Engine run LED on, place a jumper between terminals 5 & 11 or simulate high coolant signal coming from the engine. - If engine was started manually, visual and audible alarm will be present but engine will not shutdown. To shutdown, place selector switch to the OFF position - If engine was started automatically, visual and audible alarm will be present and engine will not shutdown. To shutdown, place selector switch to the OFF position - Note: Please remove jumpers and reset alarm in order to continue to the next simulation. 		
4	<p>Engine low oil pressure:</p> <ul style="list-style-type: none"> - Start engine either manually or automatically. - Engine run LED on, place a jumper between terminals 4 & 11 or simulate engine low oil pressure from the engine. Alarm will annunciate after 8 seconds - If engine was started manually, visual and audible alarm will be present but engine will not shutdown. To shutdown, place selector switch to the OFF position - If engine was started automatically, visual and audible alarm will be present and engine will not shutdown. To shutdown, place selector switch to the OFF position <p>Note: Please remove jumpers and reset alarm in order to continue to next simulation.</p>		
5	<p>Engine Overspeed:</p> <ul style="list-style-type: none"> - Start engine either manually or automatically. - Engine run light on, place a jumper between terminals 6 & 3 or simulate overspeed from the engine. - Audible and visual alarm will be present and engine will shutdown whether it was started manually or automatically <p>Note: Please remove jumpers and reset alarm in order to continue to next simulation.</p> <p>Note: Speed switch must be reset on the engine itself</p>		

6	<p>Engine fail to start: (all engines except Caterpillar)</p> <ul style="list-style-type: none"> - Set the engine to the Manual position directly on the engine control panel - Place the controller selector switch to Auto and initiate automatic engine start or start engine by pressing the Run Test Button <p>The controller will go through its cranking cycle as follows:</p> <ul style="list-style-type: none"> - 15 second cranking from battery #1 - 15 second rest - 15 second cranking from battery #2 - 15 second rest - This cycle will repeat itself three times per battery, hence six times. - Audible and visual alarm for engine fail to start will appear. - Switch the engine control panel back to OFF position and reset the alarm 		
7	<p>Stop engine by pressing "Stop" membrane button. Note: Engine will only stop if the system pressure is above the Cut-Out setting.</p>		
Field Settings:			
<p>Cut-Out Pressure: _____</p> <p>Cut-In Pressure: _____</p> <p>Minimum run period timer activated?</p> <p>Yes: _____ Set at _____ minutes. No: _____</p> <p>Sequential Start Timer?</p> <p>Yes: _____ Set at _____ seconds. No: _____</p> <p>Weekly Test Enabled?</p> <p>Yes: _____ Start (date and time) _____ No: _____</p> <p> Stop (date and time) _____</p>			
Alarm Contacts Connections:			
<p>Selector switch in OFF or HAND connected? _____ Yes _____ No</p> <p>Engine Run connected? _____ Yes _____ No</p> <p>Engine Trouble connected? _____ Yes _____ No</p> <p>Controller Trouble connected? _____ Yes _____ No</p> <p>Other contacts supplied and connected?</p> <p>Yes: _____</p> <p>No: _____</p>			
<p>Tornatech Controller S/N: _____</p> <p>Installation address: _____</p> <p>_____</p>			

Field Acceptance Test completed? ____ Yes ____ No

Field Acceptance completed by: _____

Company: _____

Date: _____

Witnessed By: _____

Company: _____

The undersigned witness has been made aware of the NFPA20 article 14.4 Periodic Inspection, Testing and Maintenance which stipulates that "Fire pumps shall be inspected tested and maintained in accordance with NFPA25 – *Standard for the Inspection, Testing and Maintenance of Water Based Fire Protection Systems*"

Comments: _____



Canada

Tornatech Inc.

7075 Place Robert-Joncas
Suite # 132
Montreal, Canada
H4M 2Z2
Tel.: + 1 514 334 0523
+ 1 800 363 8448
Fax: + 1 514 334 5448

U.S.A.

USA Sales Representative

Tel.: + 1 513 307 6766
Fax: + 1 513 759 0509

Europe

Tornatech S.p.r.l.

Avenue Sabin 3
1300 Wavre
Belgium
Tel.: + 32 (0) 10 84 40 01
Fax: + 32 (0) 10 24 75 05

Middle East

Tornatech Fz-Llc.

P.O. Box 502221
Dubai, UAE
Tel.: + 971 50 8574639

Asia

Tornatech Pte Ltd.

49B Tuas South Ave 1
Tuas Cove Industrial Centre
Singapore 637252
Tel.: + 65 6795 8114
+ 65 6795 7823
Fax: + 65 6795 3201