

||| free Evolution

Programmable controller Installation manual



CONTENTS

1	Introduction	4
1.1	General description	4
1.1.1	Specifications:	5
1.1.2	Main functions of hardware:.....	5
1.2	Models and Features.....	5
2	Mechanical Installation	6
2.1	Mechanical dimensions	8
3	Electrical connections	9
3.1	General warnings.....	9
3.1.1	Power supply - High voltage inputs (relay).....	9
3.1.2	Analogue Inputs-Probes.....	9
3.1.3	Serial connections.....	10
3.2	Wiring diagrams.....	12
3.2.1	Terminals.....	13
3.2.2	EVK1000 terminal	13
3.3	Example of analogue input connections.....	14
3.3.1	NTC/PT1000 probe connection example	14
3.3.2	0-10V transducer connection example.....	14
3.3.3	4...20mA pressure transducer connection example	14
3.3.4	Ratiometric transducer connection example	15
3.3.5	Fan module connection example	15
3.4	Serial connection examples.....	16
3.4.1	CAN connection example 1 (Field)	16
3.4.2	CAN connection example 2 (Network)	16
3.4.3	RS485 connection example.....	17
3.4.4	Example of RS485 connection with FREE smart network.....	18
3.4.5	CANOpen network connection example	19
3.5	EVS plug-in.....	20
3.5.1	EVS plug-in wiring diagrams	20
4	Technical Data	25
4.1	General specifications	25
4.2	I/O features.....	25
4.3	Display.....	27
4.3.1	Display EVK1000	27
4.4	Serials	27
4.5	Transformer	27
4.6	EVS plug-in.....	27
4.7	Mechanical dimensions	27
4.8	Permitted use	28
4.9	Improper Use	28
4.10	Disclaimer	28
5	User Interface	29
5.1	Keys.....	30
5.2	First power on	31
5.3	Menu	31
5.3.1	System Menu	31
5.3.2	BIOS Configuration	31
5.3.3	BIOS I/O Values	32
5.3.3.1	BIOS RTC Values	32
5.3.3.2	USB-Host Handling	33
6	Physical I/O configuration.....	35
6.1	Analogue inputs.....	35
6.2	Digital Inputs	36
6.3	Digital Outputs	36
6.4	Analogue Outputs	36
6.5	DIP Switches	37
6.5.1	DIP Switch Table for EVC models and EVE expansion modules	38

7	Parameters.....	40
7.1	Parameter table	40
7.1.1	Parameter table	40
8	Models and Accessories.....	50
8.1	Models	50
8.1.1	FREE Evolution models EVD 75xx with display	50
8.1.2	FREE Evolution models EVD 75xx without display	50
8.1.3	FREE Evolution EVE 75xx expansion.....	51
8.1.4	Plug-ins.....	51
8.1.5	Terminals.....	51
8.2	Accessories.....	53

1 INTRODUCTION

To allow quick, easy reference, the manual has been designed with the following features:

References	References column: A column to the left of the text contains <i>references</i> to subjects discussed in the text to help you locate the information you need quickly and easily.
Cross references	Cross references: All words in italics are listed in the analytical index with the number of the page where they are dealt with in more detail. In the "online" (computer) manual, the words in italics are "hyperlinks" (i.e. mouse-clickable links), connecting up the different parts of the manual and making it "navigable".
Highlighting icons	Some text passages are marked by icons in the <i>references</i> column, which have the following meanings:



Important! : **Information that the user must be aware of to prevent any damage to the system or hazards for people, devices, data, etc. Users MUST read and take note of these sections.**



Note / highlight: Further information on the topic in question that the user should be aware of.



Tip: A suggestion that could help the user to understand and make better use of the information provided.

1.1 General description

FREE Evolution is the top-end of the Eliwell *range* of programmable controllers suitable for a variety of requirements in the HVAC/R and other fields, to manage from the simplest to the most complex of applications.

FREE Evolution guarantees high performance in terms of memory, connectivity and *user interface* as well as straightforward programming, maintenance and servicing.

The *models* are available as a 8 DIN rail-mounted versions which saves time in terms of wiring.

In association with **FREE Evolution** hardware, there is also the **FREE Studio** development tool to quickly and reliably program and customize new programmes for any application.

The use of several different programming languages in accordance with IEC61131-3 regulations (programming standard for industrial control), makes it possible to develop new algorithms or entire programmes totally unassisted, which *can* then be uploaded to **FREE Evolution** modules via PC or standard *USB*, guaranteeing the utmost confidentiality with appropriate security.

A wide *range* of plug-in, DIN rail-mounted modules allow integration with industrial systems, BMS and *Ethernet* networks.

Ratiometric pressure sensors and remote *terminals can* also be connected with no need for any further serial interfaces.

1.1.1 Specifications:

FREE Evolution EVD / EVC has 27 inputs/outputs, 5 of which are *analogue outputs*, 6 *analogue inputs*, 7 relay *digital outputs* (or 5 relays + 2 SSRs) and 9 *digital inputs*.

FREE Evolution EVD / EVC comes in two different *models*, allowing you to choose an integrated serial as standard with or without integrated *USB* as standard (/U model).

FREE Evolution EVD comes with a built-in graphics user terminal whilst FREE Evolution EVC has no *display*, to be connected to a remote EVK graphics terminal for the configuration of BIOS *parameters*.

FREE Evolution is expandable, up to 12 extra modules.

The 8DIN format guarantees maximum flexibility and easy installation.

The FREE Evolution EVE expansion has 27 inputs/outputs, 5 of which are *analogue outputs*, and 6 *analogue inputs*.

The 8DIN format guarantees maximum flexibility and easy installation.

- - -

24V~/.. or 48V~/.. power supply.

1.1.2 Main functions of hardware:

- Parameter settings via built-in/remote terminal or via PC.
- *USB* to upload and download parameter maps.
- *Analogue Inputs* configurable as NTC 103AT/NTCNK103, PT1000, DI, 4...20mA, 0...5V ratiometric, 0...10V, or hΩ(NTC)/ daΩ(PT1000) from *parameters*.

1.2 Models and Features

-->See Appendix A - *Models and Accessories*, and *Technical Data* section.



2 MECHANICAL INSTALLATION

IMPORTANT! Always make sure the device is switched OFF before touching connections.

All operations must be carried out by qualified personnel.

Do not mount devices in extremely damp and/or dirt-laden areas; they are designed for use in places with ordinary or normal levels of contamination.

Make sure the area near the cooling slots is ventilated.

Free Evolution EVD • EVC • EVE Installation

The instrument is intended for 8DIN rail mounting.

For GUIDA DIN installation, follow the steps described below:

Move the two spring docking devices to their standby position (use a screwdriver to press against the relative compartments, see figure 1b). Then install the device on the DIN RAIL, pressing on the "spring docking devices" to put them into the locked position.

N.B.: Once assembled on the DIN RAIL, the "spring docking devices" must be turned downwards.

Assembling the EVK terminal • (Free Evolution EVP)

Designed for panel mounting.

Make a 138x68mm hole.

Remove the front panel and make 4 holes in the panel that the controller is to be mounted on (Figure 6 points A/B/C/D) or two holes (Figure 6 points E/F) of dia. 2.7 mm at the specified spacing (Figure 6).

Insert the device, fixing it with the screws. Press the front of the terminal / EVP to close.

Figure 1
Installation on DIN rail





Figure 1b
Details of spring docking devices



Assembling the EVS Plug-ins

Plug-ins are 2DIN modules that connect to a FREE Evolution EVD/EVC controller.

To assemble EVS to EVD/EVC follow the instructions:

- remove the door (if present) on the left side of the EVD/EVC controller by using fingers or a screw-driver

- anchor EVS to the EVD/EVC controller

a) via the plug-in connector, behind the removable door.

b) with the fixing screws to which the plug-in is anchored to

Follow the instructions below to install it on DIN RAIL:

- Move the spring docking devices (two for EVD/EVC, one for EVS) to his standby position (use a screwdriver).

- Install EVD/EVC+EVS on the DIN RAIL, then press the "spring docking device" which will go to the closing position.

N.B.: Once the "BASE" is mounted on the DIN RAIL, the "Spring docking device" must be turned downwards.

Figure 3






Figure 3b
Details of spring docking devices



Note. EVS - EVE expansion connection is allowed for dedicated *models* only – see [Electrical connections](#) chapter for details

2.1 Mechanical dimensions



3 ELECTRICAL CONNECTIONS

3.1 General warnings



Before doing anything, make sure the device is connected to a suitable external *transformer*. The following rules must be followed when connecting cards to each other and to the application:

- Loads that exceed the maximum limits set forth herein must not be applied to outputs.
- When connecting loads, follow connection diagrams carefully.
- To avoid electric pairings, wire all low SELV (*) utilities separately from high voltage ones.

IMPORTANT!

Make sure the machine is switched off before working on the *electrical connections*. All operations must be carried out by qualified personnel. To ensure proper connections, comply with the following:

- Power supplies other than those specified *can* seriously damage the system.
- Use cables of suitable section for the *terminals* used.
- Separate the cables of probes and *digital inputs* from inductive loads and high voltage connections to prevent any electromagnetic interference. Do not place the probe cables near other electrical equipment (switches, meters, etc.)
- Make connections as short as possible and do not wind them around electrically connected parts.
- To avoid causing static discharges, do not touch the electronic components on the boards.
- The device must be connected to a suitable *transformer* that complies with the specifications provided in the Specifications chapter.

PLUG-IN ETH

ETHERNET



The *Ethernet* connector shield is internally connected to the earth of the instrument and therefore to the reference of the input and output channels

3.1.1 Power supply - High voltage inputs (relay)

Do not exceed the maximum permitted current; for higher loads, use a contactor with sufficient power capacity.

Important!

Make sure that power supply is of the correct voltage for the instrument.

3.1.2 Analogue Inputs-Probes

Temperature
probes



Probes have no connection polarity and *can* be extended using a normal bipolar cable (note that the extension of the probes influences the instrument's EMC electromagnetic compatibility: take great care with the wiring).

Important!

Pressure probes have a specific insertion polarity which must be observed.

Signal cables (temperature/*pressure probes*, *digital inputs*, RS-485/CAN-BUS *serials* and the electronic supply) must be cabled separately from power cables.

Eliwell-supplied probes are recommended. Contact Eliwell sales department for item availability.

Pressure probes

3.1.3 Serial connections

- All *models* have an integrated **CAN** serial as standard.
- **7500 models** have an integrated **RS485** serial as standard.
- **75MP models** have an integrated MPBUS serial as standard.
- **/U models** have an integrated **USB** serial as standard.

PAY ATTENTION WHILE CONNECTING SERIAL LINES: DO NOT CABLE **RS485** IN **CAN** PORT OR VICEVERSA



By means of the *EVS plug-in* modules, further serial ports are available for integration with industrial, BMS and *Ethernet* systems.

The controller serial ports are defined as 'OnBoard' (OB), whereas the serial ports available on the EVS modules are identified with the letters PI (Plug-In).

CAN

CAN

NOTE 1

- Use a shielded and "twisted" cable with two 0.5mm² conductors, plus braiding (i.e. suggested Belden shielded cable model 3105A rated as having 120 Ohm impedance, with PVC sleeve, 2 conductors plus braiding, 22 AWG, nominal capacity between conductors 36pF/m, nominal capacity of 68pF/m between conductor and shielding).
- Follow applicable regulations relevant to the laying of cables. Make sure data transmission circuits are well separated from power lines.
- For connections over longer distances, it is better to end the line with resistors on both ends, inserting the two **R TERM** jumpers (available on the terminal board beside the **CAN** serial as the *default* factory configuration).

NOTE 2

The maximum distance depends on rated baud:

Kb/s (Kbaud)	CAN OnBoard	CAN Plug-In
50 Kbaud	1000m	1000m
125 Kbaud	500m	500m
250 Kbaud	200m	250m
500 Kbaud	30m	60m

NOTE 3

It is a 5-way terminal board:

- 3-way ("GS", "H" and "L") serial **CAN**
- 2-way POWER OUT supply for *EVK1000 terminal*.

RS485

RS485

INSTALLING THE RS-485 NETWORK

NOTE 1

Use a shielded and "twisted" cable with two 0.5mm² conductors, plus braiding (i.e. Belden cable model 8762 with PVC sleeve, 2 conductors plus braiding, 20 AWG, nominal capacity between conductors 89pF/m, nominal capacity of 161pF/m between conductor and shielding).

See standards relating to EN 50174 data transmission systems for indications on how to lay cables..

Make sure data transmission circuits are well separated from power lines.

An RS-485 network up to 1200m in length featuring a maximum of 256* devices *can* be connected straight to the controller.

Note: Evolution shall be in Master/Slave configuration with a unique Master supervisor

This length *can* be extended and the number of devices for each channel increased using appropriate repeater modules.

NOTE 2

It is a single terminal board with 3 conductors: use all 3 conductors ("+", "-" for the signal and "GS" for the braiding).

NOTE 3

Attach the 120 (Ohm) 1/4W resistors between the "+" and "-" *terminals* on the interface and the last controller in each branch of the network.

NOTE 4

Maximum speed that *can* be set 57600 baud. Higher speeds are required for local connection to FREE Studio Device and tests.

USB **On /U *models* only**

On /U *models* only there are 22 **USB** connectors inside the door on the right of the LEDs, on the top part of the cap.

N.B.: the two USBs should not be used at the same time.

Type A **USB (HOST)**

Used to connect a standard **USB** directly to download the application. This should be done from the controller keypad (EVD model) or from an **EVK1000 terminal** (EVC model).

See the section on [User Interface / USB-Host Handling](#) for handling files stored on the **USB** memory stick

Type B mini **USB (DEVICE)**

Used to connect FREE Evolution to a PC or third party device via mini **USB** cable to up/download the application or documentation. This *can* be done from a PC or other device.


N.B.: compatible with Windows XP Home and Professional, Windows 2000 and Windows Vista operating systems.

Note for developers who use FREE Studio: FREE Studio does not communicate with Evolution via **USB**



Note for developers who use FREE Studio: FREE Studio does however control the use of the **USB** serial port through the software library **fs_iec** located at

`C:\<Programs>\Eliwell\free Studio\Catalog\FreeEvolution\PLC`

The library also contains “target block” functions to be used for handling files in the internal memory of Evolution (see FREE Studio manual for details)



3.2 Wiring diagrams



3.2.1 Terminals

<i>Label</i>		<i>Description</i>	<i>Notes</i>
	4 DIP SWITCH	Dip Switch 4 positions	<i>default</i> OFF
	6 DIP SWITCH	Dip Switch 6 positions	EVC <i>Models</i> & EVE Expansions
	10 DIP SWITCH	Dip Switch 10 positions	Available under the cover
	POWER IN		
	POWER OUT	24V~/... - 48V...	POWER [Ext. Keyboard EVK] Output for remote keyboard
ANALOGUE OUTPUTS	AO1...AO5	<i>Analogue outputs</i> 1...5	
	G	Ground	
	12Vout	12V output for <i>analogue inputs</i> .	
	5Vout	5V output for ratiometric <i>analogue inputs</i> .	
DIGITAL OUTPUTS	C1 D01 D01	Output on relay 1	DO1: Normally Open DO1: Normally Closed
	C2 D02 D02	Output on relay 2	DO2: Normally Open DO2: Normally Closed
	DO3 DO4	Output on relay 3-4 also available as SSR* output	*Contact Eliwell sales department for item availability.
	C34	common <i>digital outputs</i> 3-4	
	DO5 DO6 DO7	Output on relay 5-6-7	
	C567	common <i>digital outputs</i> 5-6-7	12Amp max.
CAN	GS H L	Isolated <i>CAN</i> serial GS ground insulated serial from G	R TERM termination resistors for <i>CAN</i>
RS485	GS - +	Isolated <i>RS485</i> serial GS ground insulated serial from G	
DIGITAL INPUTS	DI1...DI4	<i>Digital inputs</i> 1...4	
	C1-4	Common <i>digital inputs</i> 1...4	
	DI5...DI8	<i>Digital inputs</i> 5...8	
	C5-8	Common <i>digital inputs</i> 5...8	
FAST D.I.	FDI	FAST digital input	Pulse/frequency counter up to 1KHz
	G	Ground GND	
ANALOGUE INPUTS	AI1...AI6	<i>Analogue Inputs</i>	
	G	Ground GND	


3.2.2 EVK1000 terminal

<i>Label</i>		<i>Description</i>	<i>Notes</i>
	POWER IN	Power Supply 24V~/... - 48V...	supply from FREE Evolution EVD/EVC or independent from mains
CAN	GS H L	Isolated <i>CAN</i> serial GS ground insulated serial from G	R TERM termination resistors for <i>CAN</i>

3.3 Example of analogue input connections

3.3.1 NTC/PT1000 probe connection example


- *Analogue inputs* AI1...AI6 are available for NTC.
- *Analogue inputs* AI3...AI6 are available for NTC/PT1000.



3.3.2 0-10V transducer connection example

- *Analogue Inputs* AI3...AI6 are available.


● Transducer 0-10V



3.3.3 4...20mA pressure transducer connection example

- *Analogue Inputs* AI3...AI6 are available.
- You are recommended to use a 4...20mA Eliwell EWPA transducer.
- If you are using a general 3-wire transducer, connect the earth wire to terminal G (GND) and the transducer power supply to the 12Vout.

● Transducer 4...20mA




FREE Evolution	EWPA	4...20mA transducer
GND	/	GND
AI3 AI4 AI5 AI6	WHITE	SIG
12Vout	BROWN	Transducer Power Supply

3.3.4 Ratiometric transducer connection example

Analogue Inputs AI3...AI6 are available.


You are recommended to use a 0-5V Eliwell EWPA ratiometric transducer.



3.3.5 Fan module connection example

- There are 5 available *analogue outputs*: AO1...AO5
- Example diagram with CFS 4 ...20mA or 0-10V fan module.


ANALOGUE OUTPUTS



3.4 Serial connection examples


3.4.1 CAN connection example 1 (Field)

- 1 FREE Evolution EVD
- 1 FREE Evolution EVE expansion connected in **CAN**
- 1 **EVK1000 terminal** connected in **CAN** to **FREE Evolution EVD**
 - The **EVK1000** terminal is supplied by EVD via the POWER OUT output.




3.4.2 CAN connection example 2 (Network)

- 1 FREE Evolution EVD
- 1 FREE Evolution EVC connected in **CAN** (binding)
- 1 **EVK1000 terminal** connected in **CAN** to **FREE Evolution EVD** or, alternatively, to **EVC**
 - The **EVK1000 terminal** is supplied by EVD via the POWER OUT output.



3.4.3 RS485 connection example

- 1 FREE Evolution EVD
- 1 FREE Evolution EVE expansion connected in [RS485](#)
- 1 **EVK1000 terminal** connected in [CAN](#) to FREE Evolution EVD
 - The **EVK1000 terminal** is supplied by EVD via the POWER OUT output.



3.4.4 Example of RS485 connection with FREE smart network

FREE Evolution


- 1 FREE Evolution EVD
- 1 **FREE Evolution EVE** expansion connected in **CAN**(°)
- 1 remote **EVK1000 terminal** connected in **CAN** to **FREE Evolution EVD**.
 - The remote **EVK1000 terminal** is supplied by EVD via the POWER OUT output.

(°) **CAN** connection may be

- Field, as of previous example
- Network while connecting one or more **FREE Evolution EVD/EVC**


FREE Smart

- 1 **FREE Smart system (Modbus Slave)** connected in **RS485** with **FREE Evolution (Modbus Master)**
- **FREE Smart** system comprising SMC/SMD (model /S), SE expansion, remote **terminals** SKP10/SKW22* connected in LAN** network.
 - *alternatively SKP22



3.4.5 CANOpen network connection example

- Max 1 **FREE Evolution EVD** that acts as **MASTER**
- Max 12 **FREE Evolution EVEs** that act as **SLAVES**
- No more than two **EVK1000 terminals** connected to **FREE Evolution EVD can** be added to the network.



3.5 EVS plug-in

Plug-ins are 2DIN modules that connect to a **FREE evolution EVD/EVC** or to an expansion **EVE*** controller via the plug-in connector on the left side of the controller, behind the removable door. The plug-in is anchored to the controller with the fixing screws.


It assembles onto the DIN rail in the same way as the controller.

*see [EVS vs EVE](#)

Plug-in	
EVS RS232	5A SPDT relay available
EVS RS485	RS485 dual network In parallel*
EVS CAN	CAN dual network In parallel*
EVS ETH (ETHERNET)	The MACADDRESS is supplied inside the pack In barcode and 12 digit alphanumeric format The <i>Ethernet</i> connector shield is internally connected to the earth of the instrument and therefore to the reference of the input and output channels
*We recommend the use of shielded cable. See Serial Connections	

3.5.1 EVS plug-in wiring diagrams

Power is supplied from FREE Evolution



The RS232 plug-in enables **FREE Evolution EVD/EVC** to communicate over an RS232 serial

Using the Modbus RTU communication protocol

The connection allows:

- Connection to a monitoring system using the Modbus RTU protocol.
- Connection of an IEC 61131-3 **FREE Studio** development system.



Using the Modbus ASCII communication protocol and or send/receive AT commands for modem⁽¹⁾.

This protocol is enabled only when a modem is connected to the plug-in

The connection allows:

- Connection to a monitoring system using the Modbus ASCII protocol.
- Connection of an IEC 61131-3 **FREE Studio*** development system.
- Send/receive TXT messages via a modem connected to the RS232 port⁽²⁾.


*Note: The plug-in has a relay that *can* be piloted from the IEC application to allow the modem to be activated/reset or as an additional digital output.

⁽¹⁾ **for developers who use FREE Studio:** refer to the software library **Modem_IEC.dll** located at
C:\<Programs>\Eliwell\free Studio\Catalog\FreeEvolution\PLC

⁽²⁾ **for developers who use FREE Studio:** refer to the software library **SMS_IEC.dll** located at
C:\<Programs>\Eliwell\free Studio\Catalog\FreeEvolution\PLC

NOTE: ref. *Parameters* chapter / RS232 PLUGIN PASSIVE *folder*

NOTE: ref. *Parameters* chapter / MODEM *folder*



EVS ETH

EVS ETH

The [Ethernet](#) plug-in enables **FREE evolution EVD/EVC** to communicate on an [Ethernet](#) network using the Modbus TCP protocol.


The connection allows:

- To connect different controllers and/or applications exchanging variables and/or [parameters](#) to be connected in a **network**.
- Connection to a monitoring system using the Modbus TCP protocol.
- Connection of an IEC 61131-3 **FREE Studio** development system.

NOTE: The MACADDRESS is supplied inside the pack In barcode and 12 digit alphanumeric format

NOTE: ref. [Parameters](#) chapter / [ETHERNET PLUGIN PASSIVE](#) *folder*

NOTE: The [Ethernet](#) connector shield is internally connected to the earth of the instrument and therefore to the reference of the input and output channels



EVS RS485

EVS RS485

The **RS485** plug-in enables **FREE Evolution EVD/EVC** to communicate over an **RS485** serial using the Modbus RTU Master/Slave communication protocol in addition to the **RS485** serial present on the base board.


The connection allows:

- Connection to a monitoring system using the Modbus RTU protocol.
- Connection of an IEC 61131-3 **FREE Studio** development system.
- Connection to Modbus peripherals (i.e. expansion EVE)

Note: The **RS485 serials** are interchangeable. FREE Evolution manages only one of the two **serials** as Modbus Master.

Both **can** be Modbus Slave

NOTE: ref. [Parameters](#) chapter / **RS485 PLUGIN PASSIVE folder**



EVS CANOpen

[EVS CANOpen](#)


The CANOpen plug-in enables **FREE evolution EVD/EVC** to communicate over an [CAN](#) serial using the CANOpen communication protocol in addition to the [CAN](#) serial present on the base board.

The connection allows:

- Connection to a monitoring system using the CANOpen protocol.
- Connection of an IEC 61131-3 **FREE Studio** development system.
- Connection to expansions EVE
- Connection to [EVK1000 terminals](#)

Note: The CANOpen *serials* are interchangeable. FREE Evolution manages only one of the two *serials* to pilot expansions or third party devices.

NOTE: ref. [Parameters](#) chapter / [CAN PLUGIN PASSIVE folder](#)



EVS vs EVE

[EVS vs EVE](#)

The *plug-ins* can connect to an EVE expansion module with certain restrictions. See the following table:

Plug-in	Connection with EVE
EVS RS232	Modbus RTU only
EVS RS485	Cannot connect to a modem (Modbus ASCII)
EVS ETH (ETHERNET)	SLAVE only
EVS CAN	NO
	SLAVE only
	OnBoard CAN serial NOT usable

4 TECHNICAL DATA

4.1 General specifications

	Standard	Min.	Max.
Supply voltage*	24V~/± 20% or 48V~/± 20%	21V	60V
Power supply frequency	50Hz/60Hz	---	---
Power draw	18W	---	---
Power draw <i>EVK1000 terminal</i>	5W	---	---
Insulation class	2	---	---
Ambient operating temperature	25°C	-10°C	55°C
Ambient operating temperature <i>EVK1000 terminal</i>	25°C	-5°C	55°C
Ambient operating humidity (non-condensing)	30%	10%	90%
Storage temperature	25°C	-20°C	85°C
Ambient storage humidity (non-condensing)	30%	10%	90%

*Note EVK1000: supply from FREE Evolution EVD/EVC or independent from mains

Note: cable must be no longer than 10m.

Classification	
The product meets the requirements of the following: European Community Directives	Directive 2006/95/EC Directive 89/108/EC
and complies with the following harmonised regulations	EN 60730-2-6 / EN 60730-2-9 / EN 60730-1
Use	in terms of construction, as a independently mounted temperature-sensitive automatic electronic controller
Mounting	Panel or on DIN Omega bar support
Type of action	1.B
Pollution class	2 (normal)
Overvoltage category	II
Nominal pulse voltage	2500V
<i>Digital outputs</i>	Refer to the <i>label</i> on the device
Fire resistance category	D
Software class and structure	A
Type of disconnection or suspension for each circuit	Microswitch disconnection
PTI of materials used for insulation:	PTI 250V
Period of electrical stress on the insulating parts	Long period

4.2 I/O features

Type and <i>Label</i>	Nr.	Description	7500 75MP	75SS
<i>Digital inputs</i> low voltage (SELV) DI1...DI8	8	8 optoisolated voltage inputs 50/60KZ mains frequency or DC signal	x	x
Digital input FAST DI	1	1 no-voltage digital input (Pulse counter)	x	x
Relay <i>digital outputs</i> High voltage DO1 DO2	7	2 x 8A 250V~ relays	x	-
Relay <i>digital outputs</i> High voltage DO3...DO7		5 x 5A 250V~ relays	x	-
Relay <i>digital outputs</i> High voltage DO1 DO2	5	2 x 8A 250V~ relays	-	x
Relay <i>digital outputs</i> High voltage DO5 DO6 DO7		3 x 5A 250V~ relays	-	x
SSR <i>digital outputs</i> High voltage DO3 DO4	2	2 x 1A 250V~ SSR	-	x

Type and Label	Nr.	Description	7500 75MP	75SS
<p><i>Analogue outputs</i> low voltage (SELV) AO1...AO5</p>	5	<p>5 x 0-10V / 4.20mA / ON-OFF configurable outputs</p> <p>0-10V 2% f.s. Load min 500Ω; 1% f.s with load over 5KΩ</p> <p>4.20mA 2% f.s. Load up to 400Ω</p> <p>ON-OFF Load up to 400Ω</p>	x	x
<p>5 <i>Analogue inputs</i> AI1 AI2</p> <p><i>Analogue inputs</i> AI3 AI4</p> <p>AI5 AI6</p>	2	<p>2 configurable inputs:</p> <ul style="list-style-type: none"> a) NTC temperature 103AT 10kΩ, measurement <i>range</i> - 50°C ÷ 110°C (-58...230°F); b) NTC temperature NK103 10kΩ, measurement <i>range</i> - 40...+150°C (-40...302°F) c) no voltage digital input 	x	x
	4	<p>4 configurable inputs:</p> <ul style="list-style-type: none"> a) NTC temperature 103AT 10kΩ, measurement <i>range</i> - 50°C ÷ 110°C (-58...230°F); b) NTC temperature NK103 10kΩ, measurement <i>range</i> - 40...+150°C (-40...302°F) c) no voltage digital input d) Pt1000 temperature measurement <i>range</i> -200...+800°C (-328...1472°F) e) Current input 4..20 mA /voltage input 0-10V/0-5V ratiometric (*) <p><i>Range</i> 0... 1000 (*) 50mA maximum current @5V</p> <ul style="list-style-type: none"> f) hΩ(NTC) g) daΩ(PT1000) <p>Accuracy: (a) (b) (d) 0.5% full scale + 1 digit (e) 1% full scale + 1 digit</p> <p>Resolution: (a) (b) (d) 0.1°C (e) 1 digit</p> <p>Input impedance (e):</p> <ul style="list-style-type: none"> • 0-10V and 0-5V: 21KΩ • 4...20mA: 100Ω 	x	x

4.3 Display

EVD *models* and remote terminal:

- backlit with LEDs +
- 3 LEDs

Note: LED and backlighting *can* be controlled from IEC application

4.3.1 Display EVK1000

Front Protection: IP65 on the front

Display: LCD monochromatic graphic *display* 128x64px backlit with LEDs

Container: bottom + frame PC+ABS UL94 V-0 plastic resing casing, front transparent polycarbonate, keypad polyester membrane

4.4 Serials

Serial	Description	Notes	Models
CAN	Open opto-isolated serial <i>CAN</i>	max50m@500kpbs 200m@125kpbs	All <i>models</i> + EVK1000 terminal
RS-485	RS-485 opto-isolated serial		EVD EVC EVE models 7500 75SS
MPBUS	MPBUS serial to pilot up to 8 Belimo actuators		EVD EVC <i>models</i> 75MP
USB	<ul style="list-style-type: none"> • 1 type A (HOST) female <i>USB</i> connector • 1 type B (DEVICE) female mini <i>USB</i> connector 	'Mass Stotage' Profile External memory Formatted FAT32 Up to 2TB	/U <i>models</i>

4.5 Transformer

The instrument must be connected to a suitable current *transformer* with the following features:

- Primary voltage: Depending on requirements of individual device and/or country of installation.
- Secondary voltage: 24V~/... - 48V~ ±20%
- Power supply frequency V~: 50/60Hz
- Power: 18W min.

4.6 EVS plug-in

	Serial	Notes	terminals
EVS RS232	RS232 null modem	<i>Digital outputs</i> 1 relay SPDT 5A 250V~	terminals 1...3 removable, screw type*, pitch 5, 90° insertion for cables with 2.5 mm ² cross-section + DB9 connector
EVSCAN	dual serial port in parallel	Open opto-isolated <i>CAN</i> serial	removable screw-type*, pitch 3.81, 90° insertion for cables with 2.5 mm ² cross- section
EVS RS-485	dual serial port in parallel	RS-485 opto-isolated serial	
EVS ETH	Modbus TCP <i>ETHERNET</i> port	MPBUS serial to pilot up to 8 Belimo actuators	RJ45 connector

*available spring-loaded from semi-finished product

Power supply: from EVD/EVC power board

4.7 Mechanical dimensions

FREE EVOLUTION EVD/EVC/EVE	Length (L) mm	Depth (d) mm	Height (H) mm	Notes
Space required	140	61.6	110	
Plug-in	Length (L) mm	Depth (d) mm	Height (H) mm	Notes
Plug-in EVS	35	61.6	110	
Terminal EVK1000	Length (L) mm	Depth (d) mm	Height (H) mm	Notes
Space required	160	10	96	
Hole for panel wall-mounting Remote terminal	68	/	138	(+0.2mm / -0.1mm)

4.8 Permitted use

For safety reasons, the instrument must be installed and used according to the instructions provided. In particular, parts carrying dangerous voltages must not be accessible under normal operating conditions.
The device must be adequately protected from water and dust with regard to the application, and must only be accessible using tools (with the exception of the front panel).
The device is suitable for use in household refrigeration appliances and/or similar equipment and has been tested for safety aspects in accordance with the harmonized European reference standards

4.9 Improper Use

Any use other than that expressly permitted is prohibited.

The relay contacts supplied are of the functional type and subject to fault (since they are electronically controlled they are prone to short-circuiting or remaining open). Any protection devices specified in product standards or suggested by common sense for obvious safety requirements must be installed externally to the device.

Eliwell is not liable for damage caused by:

- Unspecified installation/use and, in particular, in contravention of the safety requirements of established legislation or specified in this document.
- Use on equipment which does not provide adequate protection against electrocution, water and dust in the actual installation conditions.
- Use on equipment in which dangerous components *can* be accessed without the use of specific tools.
- Installation/use on equipment which does not comply with established legislation and standards.


4.10 Disclaimer

This document is the exclusive property of **Eliwell Controls srl** and may not be reproduced or circulated unless expressly authorized by **Eliwell Controls srl** itself.

Every care has been taken in preparing this document; however, **Eliwell Controls srl** cannot accept liability for any damage resulting from its use.

5 USER INTERFACE

The front panel of the device serves as the *user interface* and is used to perform all operations relating to the device.




N.B.:

- The EVC module has no *display*. To work on the device, use the remote EVK terminal.
- The EVE expansion module has no *display*.

5.1 Keys

The data provided refers to EVD *models*.



The *keys can* be programmed from the IEC application. By *default*, the device displays a short *menu* containing the following *default* settings.

Key	Key	Press once (press and release)
1	UP	<ul style="list-style-type: none"> • Scroll up. • Increase/modify a value. • Go to the next <i>label</i>.
2	OK	<ul style="list-style-type: none"> • Scroll down. • Move to next level/<i>menu</i> (open <i>folder</i>, subfolder, parameter, value). • Enter/exit edit mode. • Confirm operation.
3		<ul style="list-style-type: none"> • Moves cursor to right in Edit Mode.
4	DOWN	<ul style="list-style-type: none"> • Scroll down. • Decrease/modify a value. • Goes to the previous <i>label</i>.
5	Exit	<ul style="list-style-type: none"> • Exit <i>menu</i> page / go back to previous <i>menu</i>. • Moves cursor to left in Edit Mode. • (press and hold) Exit Edit Mode without saving any changes.

All LEDs are fully programmable via IEC application.

As *default* they are used only for *USB* management – see related paragraph *USB*-Handling

5.2 First power on

On powering up the controller for the first time, a few summary pages are displayed showing system status (**SYSTEM INFO**)

SYSTEM INFO	
HW	
BIOS	
DATE	
BOOT	

NOR FLASH	OK
NOR FLASH	OK
SDRAM	OK
BATRAM	OK
RTC	OK
Plugin	None
USB-H	OK
USB-D	Load service

5.3 Menu

By factory *default*, Free Evolution has a minimal *system menu* to configure inputs/outputs, *display* I/O values and *USB* operations where present (/U *models*). The *menu* is only available in English.

5.3.1 System Menu

System Menu	
BIOS Configuration	
BIOS I/O Values	
BIOS RTC Values	
USB-Host Handling	

5.3.2 BIOS Configuration

Parameter configuration *menu*. See *Parameters* chapter.

BIOS Configuration	
Analog Input	
Analog Output	
RS485 On Board	
CAN On Board	

The table below lists the *parameters* that *can* be configured from the LCD *display* (EVD model) and/or remote EVK terminal.

The *menu* for parameter configuration is *System Menu > BIOS Configuration*

BIOS Configuration	Parameter Folder
Analog Input	ANALOGUE INPUTS
Analog Output	ANALOGUE OUTPUTS V/I
RS485 On Board	RS485 ON BOARD
CAN On Board	CAN ON BOARD

5.3.3 BIOS I/O Values

Shows input (read only) and output values (modifiable).

BIOS I/O Values	
Analog Input	
Analog Output	
Digital Output	
Digital Input	

Inputs are read only. Digital input example:

Digital Input	
DI1 Off	DI5 Off
DI2 Off	DI6 Off
DI3 Off	DI7 Off
DI4 Off	DI8 Off

The analogue and *digital outputs* are modifiable.

Scroll to the resource required.

Press the OK key to enter Edit Mode. Use the UP and DOWN *keys* to modify value. Confirm with the OK key.

Analogue outputs example

Analogue Output 1/2	
AO1 0.2 %	
AO2 0.0 %	
AO3 0.0 %	
V Prev	Next ^

Digital outputs example

Digital Output	
DO1 On	DO5 Off
DO2 Off	DO6 Off
DO3 Off	DO7 Off
DO4 Off	

5.3.3.1 BIOS RTC Values

Shows time (HH : MM : SS) and date (DD / MM / YY) internal clock

BIOS RTC Values	
16 : 50 : 56	
30 / 10 / 10	
RTC set	

Press the OK key.

Scroll to the value required.

Press the OK key to enter Edit Mode. Use the UP and DOWN *keys* to modify value. Confirm with the OK key.

Scroll to RTC update and press the OK key to update clock

BIOS RTC Values	
17 : 50 : 56	
31 / 10 / 10	
RTC update	

5.3.3.2 USB-Host Handling

Only *models* with *USB (/U models)*

N.B.: the two USBs should not be used at the same time.



**USB -> FREE
EVOLUTION**

USB -> FREE EVOLUTION

Note. *USB type A (Host)*

Menu that allows you to upload *parameters*, applications and menus from PC to Free Evolution.

The operation should be done individually for each Free Studio development environment and for BIOS *parameters*:

- Application:
- *User Interface*
- Connection
- *Parameters*

**FREE EVOLUTION -
-> USB**

FREE EVOLUTION -> USB

Note. *USB type mini B (Device)*

Menu that allows you to download *parameters* to PC.

This should only be done for BIOS *parameters*:

- *Parameters*

USB tipo A (Host)

Connect *USB* to the PC

Check *USB* formatting: it should be FAT32:

Select Computer resources

Click the right mouse button on Removable Disc

Select Properties and check File System type: FAT32

Add to *USB* key the following files:

file	Development environment	description	notes
HMIIEC.COD	<i>User Interface</i>	<i>Menu</i>	Available after Evolution reboot
PLCIEC.COD	Application	IEC Application	
CONNEX.PAR	Connection	Network configurationFile	
PARAM.BIN	<i>Parameters</i>	<i>parameters</i>	<i>USB type A (Host)</i> 'immediate' update without need to reboot
PARAM.DAT	<i>Parameters</i>	<i>parameters</i>	<i>USB type mini B (Device)</i> 'immediate' update without need to reboot

Note. Using two or more Evolution update will be managed through dipswitch settings

File naming will have prefix 00, 01, 02, 03 etc and Evolution will load related file only if the number matches with dipswitch settings

Example1. 4 files on *USB* key. Please note files PARAM.BIN & 00PARAM.BIN are the same file

Files available on <i>USB</i> key	Dipswitch Evolution	description	notes
PARAM.BIN	00	<i>Parameters'</i> file downloaded on Evolution	See previous table
00PARAM.BIN	01	File ignored (not downloaded)	
01PARAM.BIN	01	<i>Parameters'</i> file downloaded on Evolution	
02PARAM.BIN	01	File ignored (not downloaded)	
02PARAM.BIN	02	<i>Parameters'</i> file downloaded on Evolution	

Example2.1 file on *USB* key

Files available on <i>USB</i> key	dipswitch	description	notes
02PARAM.BIN	01	File ignored (not downloaded)	'File not present' Message will appear

USB -> FREE EVOLUTION

Connect ***USB*** key

Select ***USB -> FREE EVOLUTION***

Select the item required




If download has been successful following messages will appear



N.B. If there is no file the following message will be displayed:



N.B. If there is no ***USB*** key, the following message will be displayed:



6 PHYSICAL I/O CONFIGURATION

Free Evolution
Analogue Inputs

Analogue inputs:
table

6.1 Analogue inputs

The *analogue inputs* referred to below as AI1...AI6 are 6 in total.

Using the *parameters*, a physical resource (probe, digital input, voltage/current signal) *can* be "physically" configured for each type of input:

- 2 inputs *can* be configured as *temperature probes* (NTC type probe) or as *digital inputs*.
- 4 inputs (AI3...AI6) *can* be configured as *temperature probes* (NTC or Pt1000), as *digital inputs* or as a current/voltage input (4-20mA signal/ 0-10V, 0-5V ratiometric).

Inputs *can* be "physically" configured as specified in the table below.

Parameter	Description	Value									
		0	1	2	3	4	5	6	7	8	
Cfg_AI1	Analogue input type AI1	NTC sensor (NK103)	Probe configured as no voltage digital input	NTC probe (103AT)	//	//	//	//	//	//	
Cfg_AI2	Analogue input type AI2	NTC sensor (NK103)	Probe configured as no voltage digital input	NTC sensor (103AT)	//	//	//	//	//	//	
Cfg_AI3	Analogue input type AI3	NTC sensor (NK103)	Probe configured as no voltage digital input	NTC sensor (103AT)	4-20 mA	0-10 V	0-5 V ratiometric	PT100 0	hΩ(NTC) (*)	daΩ (PT1000) (**)	
Cfg_AI4	Analogue input type AI4	NTC sensor (NK103)	Probe configured as no voltage digital input	NTC sensor (103AT)	4-20 mA	0-10 V	0-5 V ratiometric	PT100 0	hΩ(NTC)	daΩ (PT1000)	
Cfg_AI5	Analogue input type AI5	NTC sensor (NK103)	Probe configured as no voltage digital input	NTC sensor (103AT)	4-20 mA	0-10 V	0-5 V ratiometric	PT100 0	hΩ(NTC)	daΩ (PT1000)	
Cfg_AI6	Analogue input type AI6	NTC sensor (NK103)	Probe configured as no voltage digital input	NTC sensor (103AT)	4-20 mA	0-10 V	0-5 V ratiometric	PT100 0	hΩ(NTC)	daΩ (PT1000)	

NOTE: // indicates that value is not present.

(*) Cfg_Alx = 7: resistive value read, expressed in hΩ, for a resistance applied to the input using the controller in NTC configuration, i.e. **creating a divider with a pull-up resistance of 10k**.

(*) Cfg_Alx = 8: resistive value read, expressed in daΩ, for a resistance applied to the input using the controller in PT1000 configuration, i.e. **creating a divider with a pull-up resistance of 1.66k**.

Please Note. Typical use with a trimmer applied to the input

Resistance *range* for hΩ(NTC) configuration is up to 150K, while for daΩ(PT1000) configuration is up to 30K.

Parameter	range	Description
FullScaleMin_AI3	-9999...+9999	Analogue input AI3 start of scale value
FullScaleMax_AI3	-9999...+9999	Analogue input AI6 full scale value
FullScaleMin_AI4	-9999...+9999	Analogue input AI3 start of scale value
FullScaleMax_AI4	-9999...+9999	Analogue input AI6 full scale value
FullScaleMin_AI5	-9999...+9999	Analogue input AI3 start of scale value
FullScaleMax_AI5	-9999...+9999	Analogue input AI6 full scale value
FullScaleMin_AI6	-9999...+9999	Analogue input AI3 start of scale value
FullScaleMax_AI6	-9999...+9999	Analogue input AI6 full scale value

The values read by *analogue inputs* can be configured via the following *parameters*:

Parameter	Description	Measurement Unit	Range
Calibration_AI1	Analogue input AI1 differential	°C/10 or °F/10	-180 ... 180
Calibration_AI2	Analogue input AI2 differential	°C/10 or °F/10	-180 ... 180
Calibration_AI3	Analogue input AI3 differential		-1000 ... 1000
Calibration_AI4	Analogue input AI4 differential		-1000 ... 1000
Calibration_AI5	Analogue input AI5 differential		-1000 ... 1000
Calibration_AI6	AI6 analogue input differential		-1000 ... 1000

6.2 Digital Inputs

Digital Inputs

There are 8 low-voltage *digital inputs*, identified below as DI1...DI8:

They are grouped as:

- DI1...DI4
- DI5...DI8

Each with their own

There is also a fast, no-voltage digital input that acts as a pulse counter, i.e

- it detects when the contact applied to the input closes
- reads the relative frequency from 0.1Hz up to a maximum of 1KHz

6.3 Digital Outputs

Digital Outputs

See the *Electrical Connections* chapter for the number and capacity of relays and/or SSR depending on the model, and for information on the symbols used on labels supplied with the controller.

- There are 7 high voltage outputs (relays) identified as DO1...DO7.
- In *models* EVD/EVC75SS there are 5 high voltage outputs (relays) identified as DO1...DO3, DO6, DO7 whereas there are 2 SSR outputs identified as DO3...DO4.

6.4 Analogue Outputs

Analogue Outputs

See the chapter on Electric Connections for the number and type of *analogue outputs* used and for information on the symbols used on labels supplied with the controller.

There are 5 extra-low voltage (SELV) *analogue outputs* with the following characteristics:

Configuration of low voltage (SELV) analogue output

AO1/AO5	AO2	AO3	AO4
Always available Current/voltage output Low voltage (SELV) AO1 and AO5 are configured in pairs	Always available Current/voltage output Low voltage (SELV)	Always available Current/voltage output Low voltage (SELV)	Always available Current/voltage output Low voltage (SELV)
Configurable as:			
<ul style="list-style-type: none"> • 0 = 4-20mA current analogue output • Output configured as 0...20mA switch (ON= max 20mA, OFF=0mA) for piloting switch loads such as ON/OFF. • 0-10V voltage analogue output 			

6.5 DIP Switches


All *models* have a 4-position DIP switch

The EVC *models* and EVE expansion modules have, behind the door on the front panel:

- a 6-position DIP switch
- a 10-position DIP switch

Open the door with a slotted screwdriver or the nail of your index finger.

After making the configuration setting, close the front panel simply by pressing with your finger.



Default values for expansion EVE

CAN baud rate serial address	500Kb/s 1
RS485/RS232 protocol baud parity serial address	Modbus/RTU 28400 Kb/s EVEN 1

4-position DIP switch

Used for serial addressing

The address will be defined by the sum of the value of a parameter(*) plus the value defined by the DIP switch (16 addresses)

		address	DIP value	4-position DIP			
				DIP4	3	2	1
Serial Addressing	1	0	0	0	0	0	0
	2	1	0	0	0	0	1
	3	2	0	0	1	0	0
	...						
	16	15	1	1	1	1	1
OFF=0 / ON=1							

parameter	Parameter <i>default</i> (*)	address	
		LOW address	
OnBoard serials			
Addr RS485 OB	1		
Addr CAN OB	1		
Plug-In serials			
Addr RS485 PI	1		
Addr CAN PI	1		
Addr RS232 PI	1		
Ip_1 ETH PI	1		

(*) for the EVE expansion module the *default* cannot be modified

6.5.1 DIP Switch Table for EVC models and EVE expansion modules

6-position DIP switch

		baud	DIP value	DIP6	5	4	3	2	1
CAN baud rate selection	500	0	0	0	0	//	//	//	//
	250	1	0	0	1	//	//	//	//
	125	2	0	1	0	//	//	//	//
	125	3	0	1	1	//	//	//	//
	50	4	1	0	0	//	//	//	//

6-position DIP switch + 4-position DIP switch

The address will be defined by the sum of the value of the two 6- and 4-position DIP switches (127 addresses)

			6-position DIP HIGH address							4-position DIP LOW address				
			address	DIP value	DIP6	5	4	3	2	1	DIP4	3	2	1
Serial Addressing CAN	1	0	//	//	//	0	0	0	0	0	0	0	0	0
	2	1	//	//	//	0	0	0	0	0	0	0	0	1
	3	2	//	//	//	0	0	0	0	0	0	1	0	0
	...													
	127	126	//	//	//	1	1	1	1	1	1	1	1	0

10-position DIP switch

	protocol	DIP value	DIP10	9	8	7	6	5	4	3	2	1
Protocol selection	Reserved for Eliwell	0	0	//	//	//	//	//	//	//	//	//
	Modbus RTU	1	1	//	//	//	//	//	//	//	//	//
RS232/RS485 parity selection	Null	0	//	0	0	//	//	//	//	//	//	//
	Odd	1	//	0	1	//	//	//	//	//	//	//
	Even	2	//	1	0	//	//	//	//	//	//	//
RS232/RS485 baud rate selection	9600	0	//	//	0	0	0	//	//	//	//	//
	19200	1	//	//	0	0	1	//	//	//	//	//
	38400	2	//	//	0	1	0	//	//	//	//	//
	57600	3	//	//	0	1	1	//	//	//	//	//
	76800	4	//	//	1	0	0	//	//	//	//	//
	115200	5	//	//	1	0	1	//	//	//	//	//

10-position DIP switch + 4-position DIP switch

The address will be defined by the sum of the value of the two 6- and 4-position *DIP switches* (255 addresses)

			10-position DIP HIGH address										4-position DIP LOW address					
			address	DIP value	DIP10	9	8	7	6	5	DIP4	3	2	1	DIP4	3	2	1
RS232/RS485 Serial Addressing	1	0	//	//	//	//	//	//	//	//	0	0	0	0	0	0	0	0
	2	1	//	//	//	//	//	//	//	//	0	0	0	0	0	0	0	1
	3	2	//	//	//	//	//	//	//	//	0	0	0	0	0	0	1	0
	...																	
	255	254	//	//	//	//	//	//	//	//	1	1	1	1	1	1	1	0

NOTE: Different DIP switch combinations from those listed are not permitted

7 PARAMETERS

The *parameters* can be set to fully configure FREE Evolution.

They can be modified with:

- Keys on the EVD front panel or remote EVK panel.
- PC and Free Studio software

The following sections analyze each parameter, divided into categories (folders), in detail.

7.1 Parameter table

The following table shows all configuration *parameters* for the controller saved in the non-volatile memory.

Description of columns:

FOLDER

This indicates the *label* of the *folder* containing the parameter in question.

Certain folders are not available for the EVE expansion module. See the following table

FOLDER	EVD	EVE
ACKNOWLEDGEMENT	x	x
CALIBRATION AI	x	x
CALIBRATION AO	x	x
<i>ANALOGUE INPUTS</i>	x	x
<i>ANALOGUE OUTPUTS V/I</i>	x	x
<i>RS485 ON BOARD</i>	x	NO
<i>CAN ON BOARD</i>	x	NO
<i>RS485 PLUGIN PASSIVE</i>	x	NO
<i>CAN PLUGIN PASSIVE</i>	x	NO
RS232 PLUGIN PASSIVE	x	NO
<i>ETHERNET PLUGIN PASSIVE</i>	x	NO
<i>Display</i>	x	NO
Modem	x	NO

LABEL

This indicates the *label* used to *display* the *parameters* in the *menu* of the controller.

VALUE PAR ADDRESS

Indicates the address of the modbus register containing the resource that you want to access.

RESET (Y/N)

Indicates whether the device **MUST** be rebooted after the parameter has been modified.

- Y=YES the device **MUST** be switched off then back on again to modify the parameter.
- N=NO the device DOESN'T need to be switched off then back on again to modify the parameter

R/W

Indicates if resources are read/write, read-only or write-only:

- R The resource is read-only.
- W The resource is write-only.
- RW The resource can be both read and written.

DATA SIZE

Indicates the size of the data in bits.

CPL

When the field indicates “-1”, the value read by the register requires conversion, because the value represents a number with a sign. In the other cases the value is always positive or null.

To carry out conversion, proceed as follows:

- If the value in the register is between 0 and 32.767, the result is the value itself (zero and positive values).
- If the value in the register is between 32.768 and 65.535, the result is the value of the register - 65.536 (negative values).

RANGE

Describes the interval of values that can be assigned to the parameter. It can be correlated with other instrument *parameters* (indicated with the parameter *label*).

DEFAULT

Indicates the factory setting for the standard model of the instrument.

U.M.

Unit of measure for values converted according to the rules indicated in the *CPL* column.

The unit of measure shown is for example purposes only, as it may change depending on the application (e.g. *parameters* with an UoM in °C/bar could also have %RH).

7.1.1 Parameter table

(See next page)

EVD / EVE Parameters

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	RESET (Y/N)	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
ACKNOWLEDGEMENT	Par_TAB	15716	WORD		Y	RW	Map code Note: read/write parameter	0 ... 65535	0	num
ACKNOWLEDGEMENT	Par_POLI	15717	WORD		Y	RW	Model Code Note: read/write parameter	0 ... 65535	1025	num
ACKNOWLEDGEMENT	Par_PARMOD	15719	BOOL			RW	Parameter modified Flag indicating change to <i>default</i> settings. <ul style="list-style-type: none"> • 0= map not modified. • 1= at least one parameter has been modified with respect to the original configuration. 	0 ... 1	0	num
CALIBRATION AI	Gain_Ntc_Ai1	15616	WORD			RW	Ai1 NTC calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_Ntc_Ai2	15617	WORD			RW	Ai2 NTC calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_Ntc_Ai3	15618	WORD			RW	Ai3 NTC calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_PT1000_Ai3	15619	WORD			RW	Ai3 PT1000 calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_5V_Ai3	15620	WORD			RW	Ai3 0-5V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_10V_Ai3	15621	WORD			RW	Ai3 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_mA_Ai3	15622	WORD			RW	Ai3 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_Ntc_Ai4	15623	WORD			RW	Ai4 NTC calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_PT1000_Ai4	15624	WORD			RW	Ai4 PT1000 calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_5V_Ai4	15625	WORD			RW	Ai4 0-5V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_10V_Ai4	15626	WORD			RW	Ai4 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_mA_Ai4	15627	WORD			RW	Ai4 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_Ntc_Ai5	15628	WORD			RW	Ai5 NTC calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_PT1000_Ai5	15629	WORD			RW	Ai5 PT1000 calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_5V_Ai5	15630	WORD			RW	Ai5 0-5V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_10V_Ai5	15631	WORD			RW	Ai5 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_mA_Ai5	15632	WORD			RW	Ai5 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_Ntc_Ai6	15633	WORD			RW	Ai6 NTC calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_PT1000_Ai6	15634	WORD			RW	Ai6 PT1000 calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_5V_Ai6	15635	WORD			RW	Ai6 0-5V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_10V_Ai6	15636	WORD			RW	Ai6 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Gain_mA_Ai6	15637	WORD			RW	Ai6 4-20V calibration gain	0 ... 65535	32768	num
CALIBRATION AI	Offs_Ntc_Ai1	15650	WORD	-1		RW	Ai1 NTC calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_Ntc_Ai2	15651	WORD	-1		RW	Ai2 NTC calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_Ntc_Ai3	15652	WORD	-1		RW	Ai3 NTC calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_PT1000_Ai3	15653	WORD	-1		RW	Ai3 PT1000 calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_5V_Ai3	15654	WORD	-1		RW	Ai3 0-5V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_10V_Ai3	15655	WORD	-1		RW	Ai3 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_mA_Ai3	15656	WORD	-1		RW	Ai3 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_Ntc_Ai4	15657	WORD	-1		RW	Ai4 NTC calibration offset	-32768 ... 32767	0	num

<i>FOLDER</i>	<i>LABEL</i>	<i>VAL PAR ADDRESS</i>	<i>DATA SIZE</i>	<i>CPL</i>	<i>RESET (Y/N)</i>	<i>R/W</i>	<i>DESCRIPTION</i>	<i>RANGE</i>	<i>DEFAULT</i>	<i>U.M.</i>
CALIBRATION AI	Offs_PT1000_Ai4	15658	WORD	-1		RW	Ai4 PT1000 calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_5V_Ai4	15659	WORD	-1		RW	Ai4 0-5V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_10V_Ai4	15660	WORD	-1		RW	Ai4 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_mA_Ai4	15661	WORD	-1		RW	Ai4 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_Ntc_Ai5	15662	WORD	-1		RW	Ai5 NTC calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_PT1000_Ai5	15663	WORD	-1		RW	Ai5 PT1000 calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_5V_Ai5	15664	WORD	-1		RW	Ai5 0-5V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_10V_Ai5	15665	WORD	-1		RW	Ai5 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_mA_Ai5	15666	WORD	-1		RW	Ai5 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_Ntc_Ai6	15667	WORD	-1		RW	Ai6 NTC calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_PT1000_Ai6	15668	WORD	-1		RW	Ai6 PT1000 calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_5V_Ai6	15669	WORD	-1		RW	Ai6 0-5V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_10V_Ai6	15670	WORD	-1		RW	Ai6 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AI	Offs_mA_Ai6	15671	WORD	-1		RW	Ai6 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Gain_10V_Ao1	15684	WORD			RW	AO1 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_mA_Ao1	15685	WORD			RW	AO1 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_10V_Ao2	15686	WORD			RW	AO2 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_mA_Ao2	15687	WORD			RW	AO2 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_10V_Ao3	15688	WORD			RW	AO3 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_mA_Ao3	15689	WORD			RW	AO3 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_10V_Ao4	15690	WORD			RW	AO4 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_mA_Ao4	15691	WORD			RW	AO4 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_10V_Ao5	15692	WORD			RW	AO5 0-10V calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Gain_mA_Ao5	15693	WORD			RW	AO5 4-20mA calibration gain	0 ... 65535	32768	num
CALIBRATION AO	Offs_10V_Ao1	15700	WORD	-1		RW	AO1 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_mA_Ao1	15701	WORD	-1		RW	AO1 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_10V_Ao2	15702	WORD	-1		RW	AO2 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_mA_Ao2	15703	WORD	-1		RW	AO2 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_10V_Ao3	15704	WORD	-1		RW	AO3 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_mA_Ao3	15705	WORD	-1		RW	AO3 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_10V_Ao4	15706	WORD	-1		RW	AO4 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_mA_Ao4	15707	WORD	-1		RW	AO4 4-20mA calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_10V_Ao5	15708	WORD	-1		RW	AO5 0-10V calibration offset	-32768 ... 32767	0	num
CALIBRATION AO	Offs_mA_Ao5	15709	WORD	-1		RW	AO5 4-20mA calibration offset	-32768 ... 32767	0	num

<i>FOLDER</i>	<i>LABEL</i>	<i>VAL PAR ADDRESS</i>	<i>DATA SIZE</i>	<i>CPL</i>	<i>RESET (Y/N)</i>	<i>R/W</i>	<i>DESCRIPTION</i>	<i>RANGE</i>	<i>DEFAULT</i>	<i>U.M.</i>
ANALOGUE INPUTS	Temp_UM	15725	WORD		Y	RW	Temperature unit of measurement • 0 = °C • 1 = °F.	0 ... 1	0	num
ANALOGUE INPUTS	Cfg_Ai1	15726	WORD			RW	Type of analogue input Ai1 • 0= NTC (NK103) • 1= DI • 2= NTC (103AT)	0 ... 2	2	num
ANALOGUE INPUTS	Cfg_Ai2	15727	WORD			RW	Type of input analogue Ai2 See Cfg_Ai1	0 ... 2	2	num
ANALOGUE INPUTS	Cfg_Ai3	15728	WORD			RW	Type of input analogue Ai3 • 0= NTC (NK103) • 1= DI • 2= NTC (103AT) • 3 = 4...20mA • 4 = 0-10V • 5=0-5V • 6=Pt1000 • 7=hΩ(NTC) • 8=daΩ(PT1000)	0 ... 8	3	num
ANALOGUE INPUTS	Cfg_Ai4	15729	WORD			RW	Type of input analogue Ai4 See Cfg_Ai3	0 ... 8	3	num
ANALOGUE INPUTS	Cfg_Ai5	15730	WORD			RW	Type of input analogue Ai5 See Cfg_Ai3	0 ... 8	3	num
ANALOGUE INPUTS	Cfg_Ai6	15731	WORD			RW	Type of analogue input Ai6 See Cfg_Ai3	0 ... 8	3	num
ANALOGUE INPUTS	FullScaleMin_Ai3	15736	WORD	-1		RW	Analogue input Ai3 start of scale value Note: Minimum full scale: for 4mA current probes, 0-10V voltage probes at 0V, 10% ratiometric probes (0-5V) (equal to 0.5V).	-9999...+9999	0	
ANALOGUE INPUTS	FullScaleMax_Ai3	15737	WORD			RW	Analogue input Ai3 full scale value Maximum full scale: for 20mA current probes, 0-10V voltage probes at 10V, 90% ratiometric probes (0-5V) (equal to 4.5V).	-9999...+9999	1000	
ANALOGUE INPUTS	FullScaleMin_Ai4	15738	WORD	-1		RW	Analogue input Ai4 start of scale value See FullScaleMin_Ai3	-9999...+9999	0	
ANALOGUE INPUTS	FullScaleMax_Ai4	15739	WORD			RW	Analogue input Ai4 full scale value See FullScaleMax_Ai3	-999...+999	1000	
ANALOGUE INPUTS	FullScaleMin_Ai5	15740	WORD	-1		RW	Ai5 analogue input start of scale value See FullScaleMin_Ai3	-9999...+9999	0	
ANALOGUE INPUTS	FullScaleMax_Ai5	15741	WORD			RW	Ai5 analogue input full scale value See FullScaleMax_Ai3	-999...+999	1000	

FOLDER	LABEL	VAL PAR ADDRESS	DATA SIZE	CPL	RESET (Y/N)	R/W	DESCRIPTION	RANGE	DEFAULT	U.M.
ANALOGUE INPUTS	FullScaleMin_Ai6	15742	WORD	-1		RW	Ai6 analogue input start of scale value See FullScaleMin_Ai3	-9999...+9999	0	
ANALOGUE INPUTS	FullScaleMaxAi6	15743	WORD			RW	Ai6 analogue input full scale value See FullScaleMax_Ai3	-999...+999	1000	
ANALOGUE INPUTS	Calibration_Ai1	15748	WORD	-1		RW	Analogue input Ai1 differential	-180 ... 180	0	°C/10 or °F/10
ANALOGUE INPUTS	Calibration_Ai2	15749	WORD	-1		RW	Analogue input Ai2 differential	-180 ... 180	0	°C/10 or °F/10
ANALOGUE INPUTS	Calibration_Ai3	15750	WORD	-1		RW	Analogue input Ai3 differential	-1000 ... 1000	0	
ANALOGUE INPUTS	Calibration_Ai4	15751	WORD	-1		RW	Analogue input Ai4 differential	-1000 ... 1000	0	
ANALOGUE INPUTS	Calibration_Ai5	15752	WORD	-1		RW	Analogue input Ai5 differential	-1000 ... 1000	0	
ANALOGUE INPUTS	Calibration_Ai6	15753	WORD	-1		RW	Ai6 analogue input differential	-1000 ... 1000	0	
ANALOGUE OUTPUTS V/I	Cfg_AO1_AO5	15758	WORD	Y	RW		Analogue output type AO1/AO5 AO1 and AO5 are configured in pairs. See SubCfg_AO5 <ul style="list-style-type: none"> • 0 = 4-20mA current analogue output • 1 = ON/OFF output configured as 0/4...20mA switch (ON= max 20mA, OFF=0mA) for piloting switch loads such as ON/OFF. • 2=0-10V analogue output - voltage 	0 ... 2	0	num
ANALOGUE OUTPUTS V/I	Cfg_AO2	15759	WORD	Y	RW		Analogue output type AO2 <ul style="list-style-type: none"> • 0 = 4-20mA • 1 = ON/OFF • 2 = 0-10V 	0 ... 2	0	num
ANALOGUE OUTPUTS V/I	Cfg_AO3	15760	WORD	Y	RW		Type of output analogue AO3 See Cfg_AO2	0 ... 2	0	num
ANALOGUE OUTPUTS V/I	Cfg_AO4	15761	WORD	Y	RW		Analogue output type AO4 See Cfg_AO2	0 ... 2	0	num
ANALOGUE OUTPUTS V/I	SubCfg_AO5	15762	WORD	Y	RW		Analogue output AO5 sub-mode function AO1 and A5 are configured in pairs. See Cfg_AO1_AO5 <ul style="list-style-type: none"> • 0 = 4-20mA current analogue output • 1 = ON/OFF output configured as 0/4...20mA switch (ON= max 20mA, OFF=0mA) for piloting switch loads such as ON/OFF. 	0 ... 1	0	num

EVD *Parameters*

<i>FOLDER</i>	<i>LABEL</i>	<i>VAL PAR ADDRESS</i>	<i>DATA SIZE</i>	<i>CPL</i>	<i>RESET (Y/N)</i>	<i>R/W</i>	<i>DESCRIPTION</i>	<i>RANGE</i>	<i>DEFAULT</i>	<i>U.M.</i>
<i>RS485</i> ON BOARD	Addr_RS485_OB	15774	WORD		Y	RW	Integrated RS485 serial address The actual address is determined by the sum of this value + the value of the dip switch.	0 ... 255	1	num
<i>RS485</i> ON BOARD	Proto_RS485_OB	15775	WORD		Y	RW	Integrated RS485 protocol selection 2 = uNET 3 = Modbus/RTU	2 ... 3	2	num
<i>RS485</i> ON BOARD	Databit_RS485_OB	15776	WORD		Y	RW	Integrated RS485 data bit number Fixed at 8	8 ... 8	8	num
<i>RS485</i> ON BOARD	Stopbit_RS485_OB	15777	WORD		Y	RW	Integrated RS485 stop bit number • 1= 1 stop bit • 2= 2 stop bit	1... 2	1	num
<i>RS485</i> ON BOARD	Parity_RS485_OB	15778	WORD		Y	RW	Integrated RS485 protocol parity • 0= NULL • 1= ODD • 2= EVEN	0 ... 2	2	num
<i>RS485</i> ON BOARD	Baud_RS485_OB	15779	WORD		Y	RW	Integrated RS485 protocol baudrate • 0=9600 baud • 1=19200 baud • 2=38400 baud • 3=57600 baud(°) • 4=76800 baud • 5=115200 baud ° maximum speed allowed. Higher speeds are required for local connection to FREE Studio Device and tests	0 ... 5	2	num
<i>CAN</i> ON BOARD	Addr_CAN_OB	15780	WORD		Y	RW	Integrated CAN serial address The actual address is determined by the sum of this value + the value of the dip switch.	1 ... 127	1	num
<i>CAN</i> ON BOARD	Baud_CAN_OB	15781	WORD		Y	RW	Integrated CAN protocol baudrate • 2=500 Kbaud • 3=250 Kbaud • 4=125 Kbaud • 5=125 Kbaud • 6=50 Kbaud	2 ... 6	2	num

<i>FOLDER</i>	<i>LABEL</i>	<i>VAL PAR ADDRESS</i>	<i>DATA SIZE</i>	<i>CPL</i>	<i>RESET (Y/N)</i>	<i>R/W</i>	<i>DESCRIPTION</i>	<i>RANGE</i>	<i>DEFAULT</i>	<i>U.M.</i>
<i>RS485</i> PLUGIN PASSIVE	Addr_RS485_PI	15782	WORD		Y	RW	RS485 passive plug-in serial address The actual address is determined by the sum of this value + the value of the dip switch.	0 ... 255	1	num
<i>RS485</i> PLUGIN PASSIVE	Proto_RS485_PI	15783	WORD		Y	RW	RS485 passive plug-in protocol selection 2 = uNET 3 = Modbus/RTU	2 ... 3	2	num
<i>RS485</i> PLUGIN PASSIVE	Databit_RS485_PI	15784	WORD		Y	RW	RS485 passive plug-in data bit number Fixed at 8	8 ... 8	8	num
<i>RS485</i> PLUGIN PASSIVE <i>RS485</i> PLUGIN PASSIVE	Stopbit_RS485_PI	15785	WORD		Y	RW	RS485 passive plug-in stop bit number • 1= 1 stop bit • 2= 2 stop bit	1... 2	1	num
<i>RS485</i> PLUGIN PASSIVE	Parity_RS485_PI	15786	WORD		Y	RW	RS485 passive plug-in protocol parity • 0= NULL • 1= ODD • 2= EVEN	0 ... 2	2	num
<i>RS485</i> PLUGIN PASSIVE	Baud_RS485_PI	15787	WORD		Y	RW	RS485 passive plug-in protocol baudrate • 0=9600 baud • 1=19200 baud • 2=38400 baud • 3=57600 baud(^) • 4=76800 baud • 5=115200 baud ^ maximum speed allowed. Higher speeds are required for local connection to FREE Studio Device and tests	0 ... 5	2	num
<i>CAN</i> PLUGIN PASSIVE	Addr_CAN_PI	15788	WORD		Y	RW	CAN passive plug-in serial address The actual address is determined by the sum of this value + the value of the dip switch.	1 ... 127	1	num
<i>CAN</i> PLUGIN PASSIVE	Baud_CAN_PI	15789	WORD		Y	RW	CAN passive plug-in protocol baudrate • 2=500 Kbaud • 3=250 Kbaud • 4=125 Kbaud • 5=125 Kbaud • 6=50 Kbaud	2 ... 6	2	num

<i>FOLDER</i>	<i>LABEL</i>	<i>VAL PAR ADDRESS</i>	<i>DATA SIZE</i>	<i>CPL</i>	<i>RESET (Y/N)</i>	<i>R/W</i>	<i>DESCRIPTION</i>	<i>RANGE</i>	<i>DEFAULT</i>	<i>U.M.</i>
RS232 PLUGIN PASSIVE	Addr_RS232_PI	15790	WORD		Y	RW	RS232 passive plug-in serial address The actual address is determined by the sum of this value + the value of the dip switch.	0 ... 255	1	num
RS232 PLUGIN PASSIVE	Proto_RS232_PI	15791	WORD		Y	RW	RS232 passive plug-in protocol selection 2 = uNET 3 = Modbus/RTU	2 ... 3	2	num
RS232 PLUGIN PASSIVE	Databit_RS232_PI	15792	WORD		Y	RW	RS232 passive plug-in data bit number 7= 7 bit 8= 8 bit	7 ... 8	8	num
RS232 PLUGIN PASSIVE	Stopbit_RS232_PI	15793	WORD		Y	RW	RS232 passive plug-in stop bit number • 1= 1 stop bit • 2= 2 stop bit	1... 2	1	num
RS232 PLUGIN PASSIVE	Parity_RS232_PI	15784	WORD		Y	RW	RS232 passive plug-in protocol parity • 0= NULL • 1= ODD • 2= EVEN	0 ... 2	2	num
RS232 PLUGIN PASSIVE	Baud_RS232_PI	15795	WORD		Y	RW	RS232 passive plug-in protocol baudrate • 0=9600 baud • 1=19200 baud • 2=38400 baud • 3=57600 baud(^) • 4=76800 baud • 5=115200 baud ° maximum speed allowed. Higher speeds are required for local connection to FREE Studio Device and tests	0 ... 5	2	num
<i>ETHERNET</i> PLUGIN PASSIVE	Ip_1_ETH_PI	15798	WORD		Y	RW	Ethernet Passive Plug-In IP address (part 1)	0 ... 255	10	num
<i>ETHERNET</i> PLUGIN PASSIVE	Ip_1_ETH_P	15798	WORD		Y	RW	Ethernet Passive Plug-In IP address (part 2)	0 ... 255	0	num
<i>ETHERNET</i> PLUGIN PASSIVE	Ip_1_ETH_PI	15798	WORD		Y	RW	Ethernet Passive Plug-In IP address (part 3)	0 ... 255	0	num
<i>ETHERNET</i> PLUGIN PASSIVE	Ip_1_ETH_PI	15798	WORD		Y	RW	Ethernet Passive Plug-In IP address (part 4)	0 ... 255	100	num

<i>FOLDER</i>	<i>LABEL</i>	<i>VAL PAR ADDRESS</i>	<i>DATA SIZE</i>	<i>CPL</i>	<i>RESET (Y/N)</i>	<i>R/W</i>	<i>DESCRIPTION</i>	<i>RANGE</i>	<i>DEFAULT</i>	<i>U.M.</i>
Modem	Modem_RS232_Pl	15820	BOOL		Y	RW	Presence of Modem	0 ... 1	0	num
Modem	Modem_InitStr1	15821	19 BYTES		Y	RW	Modem initialization string (part I)	*****	(*)	string
Modem	Modem_InitStr2	15831	19 BYTES		Y	RW	Modem initialization string (part II)	*****		string
Modem	Modem_Hangup	15851	19 BYTES		Y	RW	Hangup String	*****	ATH0	string
(*) AT&F&C&D2E0X1S0=0										
<i>Display</i>	Hmi_Language	15819	WORD			RW	Display language	0 ... 65535	0	num
<i>Display</i>	Par_ContrLCD	15723	WORD		Y	RW	LCD Contrast Allows you to vary the LCD <i>display</i> contrast.	0 ... 64	30	Num.
<i>Display</i>	Par_BackLightTime	15724	WORD			RW	Backlight switch-on time: Allows you to vary the LCD <i>display</i> switch-on time.	0 ... 3600	10	sec

8 MODELS AND ACCESSORIES

8.1 Models

8.1.1 FREE Evolution models EVD 75xx with display

Model	<i>Relay digital outputs</i> (high voltage)	<i>SSR digital outputs</i> (high voltage)	<i>Analogue outputs</i> Safe voltage (SELV)	<i>Digital Inputs</i> Safe voltage (SELV)	<i>Digital Inputs</i> No voltage	<i>Analogue Inputs</i> Safe voltage (SELV)	Integrated USB	Integrated RS485 / MPBUS
FREE EVO Display	(DO1...DO7)	SSR	(AO1-AO5)	(DI1...DI8)	(DI)	(AI)	/U	
EVD7500/C/U	7	-	5	8	1	6	YES	485
EVD7500/C	7	-	5	8	1	6	NO	485
EVD75SS/C/U (SSR)	5	2	5	8	1	6	YES	485
EVD75SS/C (SSR)	5	2	5	8	1	6	NO	485
EVD75MP/C/U (MP-BUS)	7	-	5	8	1	6	YES	MP BUS
EVD75MP/C (MP-BUS)	7	-	5	8	1	6	NO	MP BUS
Integrated CAN as standard /C indicates the presence of the RTC - Real Time Clock SELV: SAFETY EXTRA LOW VOLTAGE All models are 8Din-mountable.								

8.1.2 FREE Evolution models EVD 75xx without display

Model	<i>Relay digital outputs</i> (high voltage)	<i>SSR digital outputs</i> (high voltage)	<i>Analogue outputs</i> Safe voltage (SELV)	<i>Digital Inputs</i> Safe voltage (SELV)	<i>Digital Inputs</i> No voltage	<i>Analogue Inputs</i> Safe voltage (SELV)	Integrated USB	Integrated RS485 / MPBUS
FREE EVO Closed	(DO1...DO7)	SSR	(AO1-AO5)	(DI1...DI8)	(DI)	(AI)	/U	
EVC7500/C/U	7	-	5	8	1	6	YES	485
EVC7500/C	7	-	5	8	1	6	NO	485
EVC75SS/C/U (SSR)	5	2	5	8	1	6	YES	485
EVC75SS/C (SSR)	5	2	5	8	1	6	NO	485
EVC75MP/C/U (MP-BUS)	7	-	5	8	1	6	YES	MP BUS
EVC75MP/C (MP-BUS)	7	-	5	8	1	6	NO	MP BUS
Integrated CAN as standard /C indicates the presence of the RTC - Real Time Clock SELV: SAFETY EXTRA LOW VOLTAGE All models are 8Din-mountable.								

8.1.3 FREE Evolution EVE 75xx expansion

Model	<i>Relay digital outputs</i> (high voltage)	<i>SSR digital outputs</i> (high voltage)	<i>Analogue Outputs</i> Safe voltage (SELV)	<i>Digital Inputs</i> Safe voltage (SELV)	<i>Digital Inputs</i> No voltage	<i>Analogue Inputs</i> Safe voltage (SELV)
FREE EVO Expansion	(DO1...DO7)	SSR	(AO1-AO5)	(DI1...DI8)	(DI)	(AI)
EVE7500	7	-	5	8	1	6
EVE75SS (SSR)	5	2	5	8	1	6

Integrated RS485/CAN as standard
SELV: SAFETY EXTRA LOW VOLTAGE
All models are 8Din-mountable.

8.1.4 Plug-ins

Model	<i>Relay digital outputs</i> (high voltage)	Serial	Dimensions	Power supply	Notes
<i>EVS RS232/R</i>	1	RS232	2Din	From base EVD/EVC	Integrated relay
<i>EVS RS485</i>	/	<i>RS485</i>	2Din	From base EVD/EVC	
<i>EVS CANOpen</i>	/	CANOpen	2Din	From base EVD/EVC	
<i>EVS CANOpen + RS485*</i>	/	<i>RS485+CANOpen</i>	2Din	From base EVD/EVC	
<i>EVS ETH</i>	/	<i>ETHERNET</i>	2Din	From base EVD/EVC	MODBUS TCP

*Contact the Eliwell Sales Office

8.1.5 Terminals


Model	Mounting	Dimensions	Display	<i>Analogue Inputs</i> Safe voltage (SELV)	Power supply	Serial
EVK1000	Panel*	160x96x10mm	LCD backlit	/	From base	CANOpen

*Contact the Eliwell Sales Office for wall-mounting *accessories*.

Wall mounting *Accessories*

*Contact the Eliwell Sales Office for wall-mounting *accessories*.

Make 4 holes in the wall of dia. 4.2 mm at the specified spacing: to fix the back-plate M3 screw are suggested. Use the two side slits, one on the upper- one on the lower side under its removable doors to break, preventing the opening of holes in the wall with the recessed-wall wiring. *Ethernet* connector wiring needs a hole in the wall as well
Make all necessary connections , then insert EVP Operator terminal (without front) in the back-plate, which serves as a panel, which should be set as an 'panel mounted' device (see Mounting chapter)



8.2 Accessories

Note: The photos are intended to show the *accessories* and are by way of example only. The dimensions shown in the figures are not to scale.

	Name	P/N	Description	Documentation / Notes
Adapters and cables		SAR0RA00X701	<i>USB</i> /485 MINI KIT adapter + <i>USB</i> cable	
				
Cable		Contact Eliwell Sales Department	<i>Ethernet</i> cable	
Transformer		TF111205	230V~/24V 35VA <i>transformer</i> N.B.: cable must be no longer than 10m.	Mounting on DIN rail
Temperature probes		SN8D6L4002	NTC Probe NK103C1R1, 4m Extended <i>range</i> (polyeser, 2-wire cable) IP65.	Instruction Sheet SN8D6L4002 GB-I
		SN691150	Probe NTC 103AT, 1.5m (plastic cap, 2-wire cable).	Instruction Sheet SN8D6L4002 GB-I
		SN8T6H1502	NTC temperature probe 5X20 1.5m TPE IP68	Instruction Sheet SN8T6H1502 GB-I
		SN8T6A1502	NTC temperature probe 6X40 1.5m TPE STEEL IP68	Instruction Sheet SN8T6H1502 GB-I
		SN8T6N1502	NTC temperature probe 6X50 1.5m TPE STEEL IP68	Instruction Sheet SN8T6H1502 GB-I

	Name	P/N	Description	Documentation / Notes
Ratiometric transducers		TD400010	Ratiometric transducer EWPA 010 R 0/5V 0/10BAR Female connector	
		TD400030	Ratiometric transducer EWPA 030 R 0/5V 0/30BAR Female connector	
		TD400050	Ratiometric transducer EWPA 050 R 0/5V 0/50BAR Female connector	
Pressure transducers		(1)	EWPA 4...20mA pressure transducer with male or female connector. <i>Range</i> -0.5/7bar to 0/50bar Depending on model	Instruction sheet 9IS64173 EWPA EN-IT-ES-DE-FR-RU
Pressure switches		(1)	HR <i>range</i> (automatic reset) - minimum 100,000 ON/OFF cycles.	
		(1)	HL <i>range</i> (manual reset) - minimum 6,000 ON/OFF cycles	
		(1)	HC <i>range</i> (automatic reset) - minimum 250,000 ON/OFF cycles	
Fan modules		For codes See instruction sheet (1)	CFS FAN MODULES Single-phase speed regulators for currents from 2A to 9A.	Instruction Sheet 8FI40014 CFS –Fan Speed Modules GB-I-E-D-F
		MW991300	CF-REL FAN MODULE 6A 230V relay	Instruction Sheet 8FI40014 CFS –Fan Speed Modules GB-I-E-D-F
		Contact Eliwell Sales Department	THREE-PHASE FAN REGULATOR (DRV 300) (1) 3 phases 12...20A/420V~ (IP22 or IP55)	Contact Eliwell Sales Department

		P/N	Description	Documentation / Notes
		BARFOTS00NH00 (¹)	RadioAdapter TTL/WIRELESS 802.15.4	Instruction Sheet 8FI40023 RadioAdapter GB-I-E-D-F Manual 9MAX0010 RadioAdapter GB-I-E-D-F
		Contact Eliwell Sales Department	WebAdapter	Instruction Sheet 9IS44065 WebAdapter GB-I-E-D-F-RUS Manual 8MA00202 WebAdapter X = 0 IT; 1 EN; 2 FR; 3 ES; 5 DE; A RU
			WebAdapter Wi-Fi	
Software Tools		Contact Eliwell Sales Department	FREE Studio	Contact Eliwell Sales Department
Demo Case		VAL00033K	FREE Evolution Simulator Case	
Back-plate		EVA00WMRC0000	Back-plate for Wall mounting Accessory	

(¹) various items available. Contact the Sales Department.

(²) Various lengths *can* be requested.

GENERAL NOTES:

- Eliwell *can* also supply a variety of different NTC probes depending on the cable type (PVC or silicon) and length.

9 ANALITIC INDEX

0	
<i>0-10V transducer connection example</i>	14
4	
<i>4...20mA pressure transducer connection example</i>	14
A	
<i>Accessories</i>	53
<i>Analogue inputs</i>	35
<i>Analogue inputs: table</i>	35
<i>Analogue Inputs-Probes</i>	9
<i>Analogue Outputs</i>	36
B	
<i>BIOS Configuration</i>	31
<i>BIOS I/O Values</i>	32
<i>BIOS RTC Values</i>	32
C	
<i>CAN</i>	10
<i>CAN connection example 1 (Field)</i>	16
<i>CAN connection example 2 (Network)</i>	16
<i>CANOpen network connection example</i>	19
<i>Cross references</i>	4
D	
<i>Digital Inputs</i>	36
<i>Digital Outputs</i>	36
<i>DIP Switch Table for EVC models and EVE expansion modules</i>	38
<i>DIP Switches</i>	37
<i>Disclaimer</i>	28
<i>Display</i>	27
<i>Display EVK1000</i>	27
E	
<i>ELECTRICAL CONNECTIONS</i>	9
<i>ETHERNET</i>	9
<i>EVK1000 terminal</i>	13
<i>EVS CANOpen</i>	24
<i>EVS ETH</i>	22
<i>EVS plug-in</i>	20; 27
<i>EVS plug-in wiring diagrams</i>	20
<i>EVS RS232/R</i>	21
<i>EVS RS485</i>	23
<i>EVS vs EVE</i>	24
<i>Example of analogue input connections</i>	14
<i>Example of RS485 connection with FREE smart network</i>	18
F	
<i>Fan module connection example</i>	15
<i>First power on</i>	31
<i>FREE EVOLUTION --> USB</i>	33
<i>Free Evolution Analogue Inputs</i>	35
<i>FREE Evolution EVE 75xx expansion</i>	51
<i>FREE Evolution models EVD 75xx without display</i>	50
<i>FREE Evolution models EVD 75xx with display</i>	50
G	
<i>General description</i>	4
<i>General specifications</i>	25
<i>General warnings</i>	9
H	
<i>Highlighting icons</i>	4
I	
<i>I/O features</i>	25
<i>Improper Use</i>	28
<i>INTRODUCTION</i>	4
K	
<i>Keys</i>	30
M	
<i>Main functions of hardware:</i>	5
<i>Mechanical dimensions</i>	8; 27
<i>MECHANICAL INSTALLATION</i>	6
<i>Menu</i>	31
<i>Models</i>	50
<i>MODELS AND ACCESSORIES</i>	50
<i>Models and Features</i>	5
N	
<i>NTC/PT1000 probe connection example</i>	14
P	
<i>Parameter table</i>	40
<i>PARAMETERS</i>	40
<i>Permitted use</i>	28
<i>PHYSICAL I/O CONFIGURATION</i>	35
<i>Plug-ins</i>	51
<i>Power supply - High voltage inputs (relay)</i>	9
<i>Pressure probes</i>	9
R	
<i>Ratiometric transducer connection example</i>	15
<i>References</i>	4
<i>RS485</i>	10
<i>RS485 connection example</i>	17
S	
<i>Serial connection examples</i>	16
<i>Serial connections</i>	10
<i>Serials</i>	27
<i>Specifications:</i>	5
<i>System Menu</i>	31
T	
<i>TECHNICAL DATA</i>	25
<i>Temperature probes</i>	9
<i>Terminals</i>	13; 51
<i>Transformer</i>	27
U	
<i>USB</i>	11
<i>USB -> FREE EVOLUTION</i>	33
<i>USB-Host Handling</i>	33
<i>USER INTERFACE</i>	29
W	
<i>Wiring diagrams</i>	12



Eliwell Controls S.r.l.

Via dell' Industria, 15 Zona Industriale Paludi
32010 Pieve d' Alpago (BL) Italy
Telephone +39 0437 986 111
Facsimile +39 0437 989 066

Sales:

+39 0437 986 100 (Italy)
+39 0437 986 200 (other countries)
saleseliwell@invensys.com

Technical helpline:

+39 0437 986 250
E-mail eliwell.freeway@invensys.com

www.elowell.com

ISO 9001

