

#### PHANTOM PILOT TRAINING GUIDE

Earning Your Stripes

# **!** CAUTION

18+



This product is not suitable for people under the age of 18. Please carefully read the "Quick Start Guide", "User Guide", disclaimer, and fully watch the "Quick Start Videos" before using the PHANTOM. Users should make every effort to fly regularly in order to improve their flight skills as an advanced level pilot  $(\star\star\star)$ . Please fly safely and responsibly.

#### Please follow these guidelines prior to flying your Phantom:

- 1 Always turn on the Remote Controller prior to turning on the Phantom.
- 2 Toggle S1, S2 to the top.
- **3** Be sure there are no distractions when you're flying.
- 4 When starting your training, be sure you are in a very large open area. Be aware of your surroundings. Always fly in areas void of obstacles and away from traffic and people.
- **6** Before actually taking off, be sure you have calibrated the compass and you have full GPS satellite reception (Slow Continuous Green Flashing).
- 6 Never fly over 400 feet.
- **7** During training, stay behind your imaginary barrier and never fly behind yourself.
- 8 When in doubt, gently pull down on the throttle stick and land.
- **9** DO NOT PANIC.

The aircraft camera should face AWAY from the pilot before takeoff.



DO NOT fly the Phantom within a radius of 2 meters.





DO NOT touch the propellers after the Phantom has been started.



# Basic Flight Maneuvers (★)


Take off and land with battery facing you.






Hover in one spot keeping battery facing you, make sure to control Left/Right/Forward/Back movement.





Rotate left, rotate right but try to keep the battery pointed at yourself.





## Basic Flight Maneuvers (★)


4 Slowly fly forward/back/left/right with back of Phantom pointed at yourself.






Fly forward to a spot 20~30 feet away.
Then fly back keeping the battery pointed at yourself.






Mark a spot (B) on the ground 10ft away from the Phantom's take off point. Hover and fly towards that spot and land at the spot (B). Then go back into a hover and bring the Phantom back to its original position (A) and land again.







## Basic Flight Maneuvers (★)








## Skilled Flight Maneuvers ( $\star$





1


## Skilled Flight Maneuvers ( $\star\star$ )




## Advanced Flight Maneuvers ( $\star \star \star$ )










#### Advanced Flight Maneuvers ( $\star$







#### Advanced Flight Maneuvers ( $\star$ $\star$ $\star$ )



#### **Emergency Situations**

#### Return Home & Land Mode

Be sure you are in a large open area. Before you take off, make sure you have a good GPS lock by ensuring your LED indicators are flashing Green. Fly the Phantom at least 50ft away from your take off point. Turn off the Remote Controller. The Phantom will enter it's failsafe Return-To-Home Mode. Let the Phantom finish it's routine and land itself within 2 meters of the take off point.

#### Intercepting Return Home & Land Mode Be sure you are in a large open area. Before you take off, make

sure you have a good GPS lock by ensuring your LED indicators are flashing Green. Fly the Phantom 50ft away from your take off point. Turn off the Remote Controller. The Phantom will enter it's failsafe Return-To-Home Mode. When the Phantom is returning home, you can intercept RTH Mode by switching the S1 Switch from the top position to the middle or lower position, then continue flying the Phantom.

